Elevator Commissioning Guide

- 1 Power Check
- 2 Elevator Commissioning Process Guide
- 3 Single Elevator Commissioning
- 4 Summary of Parameters
- 5 Product Dimensions
- 6 Error Codes

This chapter provides the operation instructions for the elevator industry. Refer to the content of this chapter, you can quickly complete the installation and commissioning of elevators, including related wiring and parameter setting.

Please pay special attention to the following precautions while operating this product.



- ☑ Be sure to turn off the power before wiring.
- ☑ When the product is energized, do not remove the cover so as to avoid the risk of electric shock.
- ☑ Terminal E⊕ must be properly grounded. The 230V series shall be grounded with Type 3 grounding; the 460V series shall be grounded with the special grounding.



- ☑ Before starting the operation, please make sure the compatibility between Delta's Integrated Elevator Drive (IED) and the motor of the elevator; please refer to Appendix A Specifications.
- ☑ When a Delta IED is in operation, do not touch the heat sink (socket) and the braking resistor to avoid the risk of burns.
- ☑ During the installation, the installation precautions must be observed; unauthorized operating environment may result in fire, gas explosion, electrical induction and other events.
- ☑ If the wiring between the Delta IED and a motor is too long, the interlayer insulation of the motor may be damaged. In this case, please replace the motor with an AC motor dedicated for Delta IED or install a reactor (Please refer to Appendix B) between Delta IED and the AC motor so as to prevent the damaged insulation from burning the AC motor.
- ☑ The rated voltage of the power system for installing the Delta IED shall not exceed 240 V for the 230 series (480V for the 460 series); and the current shall not exceed 5000A RMS (10000A RMS for the models with capacities higher than 40HP (30kW))

1 Power Check

Checks before Power is Supplied

After the control system's wiring is complete, it is necessary to check the wiring:

- 1. Check if the electrical parts and mechanical parts are connected properly so as to ensure safety.
- 2. Please refer to the Operation Manual and Wiring Instructions to check if all the connections are correct. While executing the commissioning, it is recommended to execute the operation by two or more operators; if any error occurs, shut off the power immediately.
- **3.** Check if the part numbers of devices match the requirements. The safety circuit is connected properly and the signal is normal. The door lock circuit is connected properly and the signal is normal.
- **4.** The hoistway is clear and there is no person in the elevator car; the condition is ready for safe operation of the elevator.
- 5. Be sure to check if the power to be supplied and the electrical wiring are correct. Be sure to avoid damaging Delta IED due to supplying incorrect power.
- 6. Please check if the control cabinet, motor chassis, elevator car's ground wire, and hall door's ground wire are grounded safely so as to ensure personal safety. (Note: The control box and the motor chassis shall be one-point grounded.)
- 7. Short-circuit checks for the control cabinet to the ground: if any short circuit is found for the following items (a) ~ (e), please solve the problem before supplying power to the device.
 - (a) Three phase wires of the input power cord to the ground;
 - (b) Three phase wires of the motor to the ground;
 - (c) Communication lines to the ground;
 - (d) The encoder wire to the ground.
- 8. Please make sure that the following items are grounded reliably:
 - (a) The control cabinet should be grounded;
 - (b) The motor should be grounded;
 - (c) The elevator car's ground wire should be grounded;
 - (d) The door motor should be grounded;
 - (e) The pipelines should be grounded;
 - (f) The encoder's shield at the control cabinet should be grounded;
 - (g) The encoder's shield at the motor end should be grounded.
 - (Note: For asynchronous motor: the encoder's shield should be grounded at one end. For synchronous motor: the encoder's shield should be grounded at both ends.)
- 9. Wiring checks for the communication wires, encoder wires and power cord:
 - (a) The communication cable for the hoistway should be twisted pair with a twist pitch < 35 mm;
 - (b) The communication cable for the elevator car should be twisted pair with a twist pitch < 35 mm;
 - (c) The communication cable for parallel/group control should be twisted pair with a twist pitch < 35 mm; (for group control only)
 - (d) The encoder cable and power cord should be wired in separate pipelines;

- (e) The communication cable and the power cord should be wired in separate pipelines;
- (f) The communication cable for parallel/group control and the power cord should be wired in separate pipeline (for group controlled elevators only).


List of Wiring Products

Car-Top Signal Terminal Board EA-CT01



Dimensions

Unit: mm [inch.]



Terminals	Description
I1~I9	Multi-function input terminals; front/rear door open-/close limit signals;
	front/rear door open-/close-position attained signals; front/rear door light curtain signal
SAI/SBI/GND/Vs	Analog input terminals for the connection of weighing signal input
CAN+ / CAN-	CAN communication
MOD+ / MOD-	Modbus communication
J4, J5	Connect car command board
Ob1~Ob3-COMb	Multi-function relay outputs;
Oc1~Oc3-COMc	door open/close signals; up-/down- position attained signal;
Od1~Od2-COMd	elevator car fan/lighting control;
NO-COMa/ NC-COMa	cievator car fairlighting control,


Elevator Car Command Board

EA-CP16



Dimensions

Unit: mm [inch.]



Terminals	Description
CN1	Connection to the car-top board, integrated car-top board, car display board
CN2	Extension slot for connection to another EA-CP16 (More than 16 floors applications)
JP1 ~ JP16	Elevator car's floor button plug-in
JP17 - JP24	Door open/close outputs; door open delay output; non-stop output; operator control output;
	independent operation output; fireman output, etc.

Integrated Elevator Car Command Board EA-CTP01



Terminals	Description
I1 ~ I9	Multi-function input terminals Front/rear door open-/close- position attained signals; front/rear door light curtain signal;
SAI/SBI GND/Vs	Analog input terminals for the connection of weighing signal input
CAN+ / CAN-	CAN communication
MOD+ / MOD-	Modbus communication
CN1	Extension slot for connection to the car command board (primary) (More than 16 floors applications)
CN2	Extension slot for connection to the car command board (secondary) (More than 16 floors applications)
JP1 ~ JP16	Elevator car's floor button plug-in
JP17 ~ JP24	Door open/close outputs; door open delay output; non-stop output; attendant operation output; independent operation output; fireman output, etc.
Ob1~Ob3-COMb	Multi-function relay outputs
Oc1~Oc3-COMc	Door open/close signals; Up-/down-to-position signals;
Od1~Od2-COMd NO-COMa/ NC-COMa	Elevator car fan/light control;


Vertical/Horizontal Matrix Display Board

EA-FM02MH



Dimensions

Unit: mm [inch.]



Terminals	Description
J1	Modbus communication and power cord terminals, 4-pin interface: Pin 2 and Pin 3 are Modbus communication cable wires; Pin 1 and Pin 4 are for power wiring.
J2, J3	Up/Down call button interface: Pin 2 and Pin 3 are wires for digital input wiring; Pin 1 and Pin 4 are used for button indicator output signal control
J4	For up-/down-position attained indicator output signal control
J5	Fire/Lock button interface: Pin 1 and Pin 4 are used for Fire button input; Pin 2 and Pin 3 are used for Lock button input


Vertical Display Board

EA-FM02MV



Dimensions

Unit: mm [inch.]



Terminals	Description
J1	Modbus communication and power cord terminals, 4-pin interface: Pin 2 and Pin 3 are
	Modbus communication cable wires; Pin 1 and Pin 4 are for power wiring.
J2, J3	Up/Down call button interface: Pin 2 and Pin 3 are wires for digital input wiring; Pin 1 and
	Pin 4 are used for button indicator output signal control
J4	Fire button interface: Pin 2 and Pin 3 are wires for number of input switches; Pin 1 and Pin 4
	are used for button indicator output signal control
J5	Lock button interface: Pin 2 and Pin 3 are wires for number of input switches; Pin 1 and Pin
	4 are used for button indicator output signal control

Digital Input Card

EMED-D411A110V



* This digital input card is supplied with 110Vac.


Terminals	Description	
HCM	AC power common node for digital Multi-function input terminals	
HI1 ~ HI4	Input Voltage: 100VAC ~ 130VAC	
	Input frequency: 47 ~ 63 Hz	

PG Feedback Card EMED-PGAB Unit: mm [inch.] 53.0(2.09) 47.0(1.85)(2X) TB2 TB2 TW W W W VP 2945440300 SW1

※ The open-collector, Line Driver, and U V W encoder

signal are supported.


Term	Terminals Description		
TB1	VP	Encoder power output Output voltage: +5V/+12V (+5V/+12V is determined by SW1)	
		,Maximum output current: 200mA	
	0V	Common node for encoder power	
	A, /A, B, /B, Z	Encoder signal input	
	/Z	Line Driver input complies with RS422 standard	
		Single-ended input specifications: to receive a +12 V open collector signal (which is	
		determined by SW2)	
		Maximum input frequency: 100kHz	
	U, /U, V, /V,	Encoder differential absolute signal input	
	W, /W	Maximum input frequency: 50kHz	
SI	W1	Encoder 5V/12V switch	
SI	N2	Input open collector/Line Driver switch	




* Heidenhain ERN1387, EnDat2.1, and HIPERFACE are


supported.

	Terminals	Description
	Vin	Input voltage (the voltage amplitude for adjusting the push-pull pulse output) Maximum input voltage: 24VDC
	GND	Common node for input power/output signals
TB1	A/O, B/O	Push-pull pulse output signal Maximum output current: 20mA Maximum output frequency: 100kHz
3,	AO, /AO, BO, /BO	Differential pulse output signal Maximum output current: 50mA Maximum output frequency: 100kHz
D-SU	JB 9 Connector (J3)	Encoder signal input Heidenhain ERN1387 Encoder is supported Heidenhain EnDat2.1 SICK HIPERFACE
	SW1	To switch between IN.P and EX.P
	SW2	Encoder 5V/12V switch





TYPE	L1	L2	Н	D	W	MAX. WEIGHT (g)
BR080W200	140	125	20	5.3	60	160
BR080W750	140	125	20	5.3	60	160
BR300W070	215	200	30	5.3	60	750
BR300W100	215	200	30	5.3	60	750
BR300W250	215	200	30	5.3	60	750
BR300W400	215	200	30	5.3	60	750
BR400W150	265	250	30	5.3	60	930
BR400W040	265	250	30	5.3	60	930



2 Elevator Commissioning Process Guide

Elevator Commissioning Process




Figure D1-1

Flow chart of basic parameter commissioning for slow car movement

Elevator Basic/Others Parameter Settings




Figure D1-2

Flow chart for motor tuning Induction motor tuning




Figure D1-3

Synchronous motor tuning





Figure D1-4

Commissioning flow chart for fast car movement



Wiring diagram

Overall wiring





Figure D1-6

Control board layout 1



APG feedback (J6)

EMED-PGAB EMED-PGHSD



B MI power source Jumper (J7) Switch (SW1) Sink/Source


Programing port / Hoist

E keypad port (RJ45)

controller monitoring port

O I/Oextension slot (J5)

EMED-D411A



- Serial communication (TB6) Connect to CANBUSof car-top board /MODBUS of display board. Please refer to figure D1-8.
- 2 MODBUS communication (for group control) (TB7)
- 3 Analog input (TB8)
- 4 MI1~MI10 input terminal (functions can be set) (TB4)
- (5) MI11~MI24 input terminal (functions can be set)(TB5)
- 6 24V power supply input (TB2)
- Relay output terminal (functions can be set)(R3A/R4A/R34C/R5A/R6A/R56C) (TB3)
- Relay output terminal (functions can be set)(RA/RB/RC/MRA/MRB/MRC/R1A/R2A/R12C) (TB1)

Figure D1-7

Serial Communication (TB6) Connect to CANBUS of car-top board/MODBUS of display board




Figure D1-8-1

Serial Communication (TB6) Connect to CANBUS of car-top board/MODBUS of display board




Figure D1-8-2

Serial Communication (TB6) Connect to CANBUS of car-top board/MODBUS of display board




Figure D1-8-3

Control board layout 2




Figure D1-9





Figure D1-10



Car-top board layout EA-CT01




Figure D1-11

Car-top board EA-CT01 SOURCE Mode





Figure D1-12

Car-top board EA-CT01 SINK Mode



Elevator car Command board EA-CP16




Figure D1-14

Vertical display board EA-FM02MV & Vertical/Horizontal display board EA-F02MH





Figure D1-15

Digital Operation Panel



LED Segment	LED Segment "ON" indicates	LED Segment "OFF" indicates
А	MI1 Input function is valid	MI1 Input function is invalid
В	MI2 Input function is valid	MI2 Input function is invalid
С	MI3 Input function is valid	MI3 Input function is invalid
D	MI4 Input function is valid	MI4 Input function is invalid
E	MI5 Input function is valid	MI5 Input function is invalid
F	MI6 Input function is valid	MI6 Input function is invalid
G	MI7 Input function is valid	MI7 Input function is invalid
DP	MI8 Input function is valid	MI8 Input function is invalid
	A B C D E F G	A MI1 Input function is valid B MI2 Input function is valid C MI3 Input function is valid D MI4 Input function is valid E MI5 Input function is valid F MI6 Input function is valid G MI7 Input function is valid

A	Α	MI9 Input function is valid	MI9 Input function is invalid
F	В	MI10 Input function is valid	MI10 Input function is invalid
E G C	С	MI11 Input function is valid	MI11 Input function is invalid
D DP	D	MI12 Input function is valid	MI12 Input function is invalid
2	E	MI13 Input function is valid	MI13 Input function is invalid
	F	MI14 Input function is valid	MI14 Input function is invalid
	G	MI15 Input function is valid	MI15 Input function is invalid
	DP	MI16 Input function is valid	MI16 Input function is invalid
A	Α	MI17 Input function is valid	MI17 Input function is invalid
F	В	MI18 Input function is valid	MI18 Input function is invalid
E G C	С	MI19 Input function is valid	MI19 Input function is invalid
D DP	D	MI20 Input function is valid	MI20 Input function is invalid
3	E	MI21 Input function is valid	MI21 Input function is invalid
	F	MI22 Input function is valid	MI22 Input function is invalid
	G	MI23 Input function is valid	MI23 Input function is invalid
	DP	MI24 Input function is valid	MI24 Input function is invalid
	А	XI1 Input function is valid	XI1 Input function is invalid
	В	XI2 Input function is valid	XI2 Input function is invalid
	С	XI3 Input function is valid	XI3 Input function is invalid
A	D	XI4 Input function is valid	XI4 Input function is invalid
F	E	XI5 Input function is valid	XI5 Input function is invalid
E G C	F	XI6 Input function is valid	XI6 Input function is invalid
D DP	G	XI7 Input function is valid	XI7 Input function is invalid
4	DP	XI8 Input function is valid	XI8 Input function is invalid

Figure D1-16

3 Single Elevator Commissioning

Basic system settings

Basic parameters

** Before commissioning, it is necessary configure the following basic parameters. Basic motor parameter settings can be configured according to the motor's nameplate.

Paramete	Name of the parameter	Default value		Parameter range	
01-01	Parameter management setting	0		en parameter(☑)	.35
01-02	Control method	0	0: V/F control 1: V/F control + E 2: Sensorless ver 3: FOC vector co	Encoder (VFPG) ctor control (SVC) ntrol + Encoder (FOCPG) + Encoder (TQCPG)	
01-03	System control	0480Hex	bit 7=0: No functi bit 7=1: Startup p bit 10=0: No func bit 10 = 1: Direct bit 15=0: No func	omatic adjustment, PDFF enable on osition control is enabled tion parking is enabled	ower on
01-04	Elevator speed	1.00 m/s	0.10 ~ 4.00 m/s		
01-05	Maximum Output Frequency	60.00 Hz /50.00Hz	10.00 ~ 400.00H	2	9
01-08	Carrier Frequency	12 kHz	2 ~ 15kHz		
02-00	Motor Auto Tuning	0	0: No function 1: Rolling test 2: Static test		
02-01	Full-load Current of Motor	90% of the model's rated current	(30 ~ 120%) * the	e model's rated current (Amps)	100
02-02	Rated power of Motor	#.##	0.00 ~ 655.35kW		
02-03	Rated speed of Motor (rpm)	1710	0~65535	.0	
02-04	Number of Motor Poles	4	2~96	700	
02-05	Angle between Magnetic Pole and PG Origin	360.0°	0.0~360.0°		
02-06	Output Direction Selection	0		onfigured direction e configured direction	
02-07	Encoder type selection	0	0: No function 1: ABZ 2: ABZ + Hall 3: SIN/COS + Sir 4: SIN/COS + En 5: SIN/COS + Hip	dat	. 130
02-08	Encoder Pulse	600	1~25000		
02-09	Encoder's input type setting	0		re pulse inputs: Phase A is 90 degr Phase B with forwar re pulse inputs: Phase B is 90 degr	d rotation
			3: Phase A is a p	Phase A with forwar ulse input; Phase B is the direction in	

			Lie reverse direction and LLie femueral direction			
	UP III	et.	L is reverse direction and H is forward direction 4: Phase A is a pulse input; Phase B is the direction input: L is forward direction and H is reverse direction 5: Single phase input			
02-11	Rated frequency of Motor	60.00 Hz /50.00 Hz				
02-12	Rated voltage of Motor		230V Series: 0.0V ~ 255.0V 460V Series: 0.0V ~ 510.0V			
02-13	No-load current of Motor		0 ~ Motor's full-load current (Parameter 02-01) setting			
02-14	Stator Resistance (Rs) of Motor	Automatic verification after motor tuning	0.000~65.535Ω			
02-15	Rotor Resistance (Rr) of Motor	Automatic verification after motor tuning	0.000~65.535Ω			
02-16	Magnetizing Inductance (Lm) of Motor	Automatic verification after motor tuning	0.0~6553.5mH			
02-17	Stator Inductance (Lx) of Motor	Automatic verification after motor tuning	0.0~6553.5mH			
02-18	Back Electromotive Force	Automatic verification after motor tuning	0.0~6553.5Vrms			
06-10	Floor search speed	0.08 m/s	0.10 ~ 4.00m/s			
06-11	Inspection speed	0.08 m/s	0.10 ~ 4.00m/s			
06-12	Leveling speed	0.15 m/s	0.10 ~ 4.00m/s			
06-13	Fast operating speed	0.25 m/s	0.10 ~ 4.00m/s			
08-00	Elevator's topmost floor	5	Floor 1 ~ 47			
08-02	Elevator base station	1	Floor 1 ~ 47			
08-05	Service floor 1	FFFF	0~FFFF			
08-06	Service floor 2	FFFF	0~FFFF			
08-07	Service floor 3	FFFF	0~FFFF			
08-51	Automatic fault resets time	0	0: Disable 0 ~ 30000 times			
08-52	Interval of automatic reset	0	0 ~ 60 seconds			
08-48	Factory function 1	0080h	0~65535			
08-49	Factory function 2	0	0~65535			
09-02	Door motor 1 Service Floor 1	FFFF	0~FFFF			
09-03	Door motor 1 Service Floor 2	FFFF	0~FFFF			
09-04	Door motor 1 Service Floor 3	FFFF	0~FFFF			

Multi-function input terminals: Determine whether the external terminal signal is normally open (N.O.) or normally closed (N.C.); configure the following parameters after the device is supplied with power: ** Parameters 03-00=1 is used for inspection (N.O.); configure it as 101 for inspection (N.C.) (Please refer to Figure D1-5)

	Name of the parameter	NO	NC	Parameter range
03-00	Multi-function input	1	101	0: No function
	command 1 (MI1)			1: Inspection signal
03-01	Multi-function input	2	102	2: Inspection up-going
	command 2 (MI2)			3: Inspection down-going
03-02	Multi-function input	3	103	4: Upper leveling signal
	command 3 (MI3)			5: Lower leveling signal
03-03	Multi-function input	4	104	6: Door position input
	command 4 (MI4)			7: Door inter-lock circuit feedback
03-04	Multi-function input	5	105	8: Brake circuit feedback
	command 5 (MI5)			9: Operation output feedback
03-05	Multi-function input	6	106	10: Safety circuit feedback
	command 6 (MI6)			11: Up-most limit signal
03-06	Multi-function input	7	107	12: Upward 1 st level forced deceleration
	command 7 (MI7)			13: Upward 2 nd level forced deceleration
03-07	Multi-function input	8	108	14: Upward 3 rd level forced deceleration
	command 8 (MI8)			15: Down-most limit signal
03-08	Multi-function input	9	109	16: Downward 1 st level forced deceleration
7	command 9 (MI9)		}	17: Downward 2 nd level forced deceleration
03-09	Multi-function input	10	110	18: Downward 3rd level forced deceleration
	command 10 (MI10)			19: Door pre-opening output feedback
03-10	Multi-function input	11	111	20: Safety circuit feedback 2
00 10	command 11 (MI11)	11		21: Brake close feedback 2
03-11	Multi-function input	12	112	22: Door close circuit feedback 2
03-11	command 12 (MI12)	12	112	23: Overload input
03-12	Multi-function input	13	113	24: Full-load input
03-12	command 13 (MI13)	13	113	25: Fire signal
03-13	Multi-function input	14	114	26: Fire mode
03-13	command 14 (MI14)	14	114	27: Light curtain signal 1
03-14		15	115	28: Light curtain signal 2
03-14	Multi-function input	15	115	29: Elevator lock signal
03-15	command 15 (MI15)	16	116	30: Emergency power supply feedback
03-15	Multi-function input	10	116	
02.40	command 16 (MI16)	47	447	
03-16	Multi-function input	17	117	M. W. M.
00.47	command 17 (MI17)	10	440	1111
03-17	Multi-function input	18	118	
00.10	command 18 (MI18)		-	
03-18	Multi-function input	0	0	W. W.
	command 19 (MI19)			
03-19	Multi-function input	0	0	W .0' ^
	command 20 (MI20)			- 'Ok "Ch
03-20	Multi-function input	0	0	V 74.
	command 21 (MI21)			
03-21	Multi-function input	0	0	N. N. O.
	command 22 (MI22)			
03-22	Multi-function input	0	0	√ "7/".
	command 23 (MI23)			
03-23	Multi-function input	0	0	
	command 24 (MI24)			

Multi-function input terminals: Determine whether the external terminal signal is normally open (N.O.) or normally closed (N.C.); configure the following parameters after the device is supplied with power:

※ Please refer to Figure D1-5

Parameter	Name of the parameter	NO	NC	Parameter range
03-40	Multi-function output RA	1	101	0: No function
03-41	Multi-function output MRA	2	102	1: Motor's solenoid valve control output
03-42	Multi-function output R1A	3	103	2: Mechanical brake release
03-43	Multi-function output R2A	0	0	3: Mechanical brake enhanced release
03-44	Multi-function output R3A	0	0	4: Mechanical brake, electromagnetic contactor normal
03-45	Multi-function output R4A	0	0	5: Fault output
03-46	Multi-function output R5A	0	0	6: Operation monitoring
03-47	Multi-function output R6A	0	0	7: Group control ready 8: Door pre-opening contactor output
				9: Door motor 1 open 10: Door motor 1 close
				11: Door motor 2 open
				12: Door motor 2 close
				13: Door inter-lock circuit output
				14: Emergency power output
				15: PM motor three-phase short circuit output

Settings for various accessory cards

Car-top board EA-CT01 input terminals & Command board EA-CP16 Input Terminals

Please refer to Figures D1-6 ~ D1-12

aramete	r Name of the parameter	NO	NC	Parameter range
10-00	Car-top board input command I1	1	101	0: No function 1: Front door open limit
10-01	Car-top board input command I2	2	102	2: Front door close limit 3: Front door light curtain input
10-02	Car-top board input command I3	3	103	4: Front door open request 5: Rear door open limit
10-03	Car-top board input command I4	5	105	6: Rear door close limit 7: Rear door light curtain input
10-04	Car-top board input command I5	6	106	8: Rear door open request 9: Overload input
10-05	Car-top board input command I6	7	107	10: Full-load input 11: Front door open button
10-06	Car-top board input command I7	9	109	12: Front door close button 13: Front door open delay button
10-07	Car-top board input command I8	10	110	14: VIP mode switch 15: Operator control switch
10-16	Command board 1 JP17	11	111	16: Operator non-stop control switch 17: Independent operation switch 18: 1 st level fire rescue switch
10-17	Command board 1 JP18	12	112	18: 1 level fire rescue switch 19: Car-top inspection switch 20: Car-top inspection up-going
10-18	Command board 1 JP19	13	113	21: Car-top inspection dp-going 21: Car-top inspection down-going 22: Emergency stop input
10-19	Command board 1 JP20	14	114	23: Light control input 24: Fan control input
10-20	Command board 1 JP21	15	115	25: Rear door open button 26: Rear door close button
10-21	Command board 1 JP22	16	116	27: Rear door open delay button 28: Operator direction up-going switch
10-22	Command board 1 JP23	17	117	29: Operator direction down-going switch

10-23	Command board 1 JP24	18	118	30: Jog up-going 31: Jog down-going 32: Light load switch input 33: Front door safety panel	Refer
				34: Rear door safety panel	

Car-top board EA-CT01 output terminals & Command board EA-CP16 Output Terminals

※ Please refer to Figures D1-6 ~ D1-12

Parameter	Name of the parameter	NO	NC	A.G	Parameter range	
	Car-top board output	1	101	0: No function		
10-24	command Od2			1: Front door o	open output	
10-25	Car-top board output	2	102	2: Front door of	close output	
10-25	command Od1			3: Rear door o	•	
10-26	Car-top board output	3	103	4: Rear door o	·	
10-20	command Oc3	27.5		5: Overload signal	•	
101-77	Car-top board output	5	105	6: Full-load sig	•	
	command Oc2			7: Buzzer outp		
111-78	Car-top board output	6	106	8: Light output	.0"	
	command Oc1	_		9: Fan output 10: Front door	is opening	
111 <u>-</u> 70	Car-top board output	7	107	11: Front door	. 0	
	command Ob3		100		open delay display	
10-30	Car-top board output	9	109		operation display	
	command Ob2	10	110	14: Operator of	•	
10-31	Car-top board output	10	110	·	lirection change display	
	command Ob1 Car-top board output	0	0	1	ent operation display	
111 /18	command Oa				e rescue display	
		10	110	18: Elevator la	nding	
10-40	Command board 1 JP17			19: Elevator st		
10-41	Command board 1 JP18	11	111		p-going output	
10-42	Command board 1 JP19	12	112		own-going output	
10-42	Command Doald 1 JF 19		440	22: Error displ	•	
10-43	Command board 1 JP20	13	113	23: Front door		
10-44	Command board 1 JP21	14	114		slow closing output	
		15	115	25: Rear door	•	
10-45	Command board 1 JP22	15	115		slow closing output	
10-46	Command board 1 JP23	16	116	27: Rear door 28: Rear door	. •	
		17	117		open delay display	
10-47	Command board 1 JP24	17	'''	25. 1.041 4001	open delay diopiay	
10-49	Car-top input direction 1	0000H	0~66535		71/22 V.C	
10-50	Car-top input direction 2	0000H	0~66535	3		
10-51	Car-top output direction 1	0000H	0~66535			6
10-52	Car-top output direction 2	0000H	0~66535			

Door control parameter settings

Parameter	Name of the parameter	Default value	Parameter range
09-00	Number of door motors	0	0: 1 unit 1: 2 units
09-01	Car-top board software version	0	0~99
09-02	Door motor 1 Service Floor 1	FFFF	0~FFFF
	Door motor 1 Service Floor 2	FFFF	0~FFFF
09-04	Door motor 1 Service Floor 3	FFFF	0~FFFF
	Door motor 2 Service Floor 1	FFFF	0~FFFF
09-06	Door motor 2 Service Floor 2	FFFF	0~FFFF
09-07	Door motor 2 Service Floor 3	FFFF	0~FFFF
09-08	Door open time protection	10	5 ~ 99 seconds
09-09	Door close time protection	15	5 ~ 99 seconds
09-10	Door open/close times	0	0 ~ 20 times
09-11	Door status at movement base station	0	O: Normal door closing Open door and wait
	Door open holding time by external display board	5	1 ~ 30 seconds
09-13	Door open holding time by in-car display board	3	1 ~ 30 seconds
09-14	Door open holding time at base station	10	1 ~ 30 seconds
09-15	Delay time for arrival alarm output	0	0 ~ 1000ms

Service Floor Parameters

Paramete	Name of the parameter	Default value	110	Parameter range	
08-05	Service floor 1	FFFF	0~FFFF		
08-06	Service floor 2	FFFF	0~FFFF		
08-07	Service floor 3	FFFF	0~FFFF		

External display board/ In-car display board


External display board/ In-car display board: Installation

Plug the connector of Modbus communication cable into J1; plug the connectors of the Upward and Downward buttons into J2 and J3, respectively; plug the connectors for the Fireman and Elevator Lock switches into J4 and J5, respectively.(Please refer to the following figure)

External display board: Floor setting

With the SW2(EA-FM02MV) & SW3 (EA-FM02MH) DIP address setting, up to 64 floors can be configured currently; the 8th bit is the termination resistor for communication; dial it to the ON position for the lowest floor. (Please refer to the following figure:)


SW1 in EA-FM02MH is to switch vertical / horizontal display. When SW1 is in 1, EA-FM02MH will be vertical display; when SW1 is in 2, EA-FM02MH will be horizontal display



Input/Output Pin Assignments


Name of the terminal	Definition of function	Description of the terminal
J1	Modbus communication and power cord terminals MOD+/MOD- are the communication lead wires for Modbus +24V/COM are the 24V power and the common ground wires, respectively	Communication port and the car-top communication Power requirements: +24V±5% Load capability ≥ 400mA
J2	Upward call button interface: Pin 2 and Pin 3 are wires for number of input switches; Pin 1 and Pin 4 are used for button indicator output signal control	1 The button is a normally open button2 The maximum load capability of the button indicator output is 30mA.
J3	Downward call button interface: Pin 2 and Pin 3 are wires for number of input switches; Pin 1 and Pin 4 are used for button indicator output signal control	in the same
J4	EA-FM02MV: Fire button interface: Pin 2 and Pin 3 are wires for number of input switches; Pin 1 and Pin 4 are used for button indicator output signal control EA-FM02MH: For the indicator of up-going and down-going position attained	Mand in the lift of lift of
J5	EA-FM02MV: Elevator lock button interface: Pin 2 and Pin 3 are wires for number of input switches; Pin 1 and Pin 4 are used for button indicator output signal control EA-FM02MH: Door lock and fire indication are Pin 4 and Pin 3,	West Manying in

The specific assignments of the 4 pins in the 4-pin interface of the EA-FM02MV are as shown below; the definitions of the labels in the figure are: +24 V (24V power), KEY-IN (button input signal), and KEY-LED (button indicator output)




Pin assignments of the terminal interface and its external connection


The specific assignments of the 4 pins in the 4-pin interface of the EA-FM02MH are as shown below; the definitions of the labels in the figure are: +24 V (24V power), KEY-IN (button input signal), KEY-LED (button indicator output), LED-FIRE (fire indicator output), LED-LOCK (door lock indicator output), KEY-FIRE (fire input signal), and KEY-LOCK (door lock input signal).



Pin assignments of the J2 and J3 terminal interfaces and their external connection



Pin assignments of the J4 terminal interface and the external connection



Pin assignments of the J5 terminal interface and its external connection

In-car display board:





EA-FM02MV

EA-FM02MH

1 Floor address setting and installation

- 1) Toggle NO.1~8 DIP of SW2(EA-FM02MV) & SW3 (EA-FM02MH) to off, the in-car display mode is activated.
- 2) SW1 in EA-FM02MH is to switch vertical / horizontal display. When SW1 is in 1, EA-FM02MH will be vertical display; when SW1 is in 2, EA-FM02MH will be horizontal display.
- 3) Plug Modbus cable terminal into J1, up-going and down-going button into J2, J3 respectively, and door inter-lock and fire mode into J4, J5.

2 . EA-FM02MV display instructions

Chart	Explanation
Upward arrow	Elevator is stopping, and about to going up
Upward arrow moving	Elevator is going up
Downward arrow	Elevator is stopping, and about to going down
Downward arrow moving	Elevator is going down
No display	Elevator is in stop mode or disconnect with IED/ Elevator lock
	mode
Display "X"	Elevator failure or communication abnormality
The state of the	
	The state of the s

3 . EA-FM02MH display instructions

A. Horizontal display

Chart	Explanation
Upward arrow	Elevator is stopping, and about to going up
Upward arrow moving	Elevator is going up
Downward arrow	Elevator is stopping, and about to going down
Downward arrow moving	Elevator is going down
No display	Elevator is in stop mode or disconnect with IED/ Elevator lock
	mode

Display "X"	Elevator failure or communication abnormality	
: History	illico Anni	
Display wrench	Elevator is under inspection	
	The state of the s	

B. Vertical display

Explanation
Elevator is stopping, and about to going up
Elevator is going up
Elevator is stopping, and about to going down
Elevator is going down
Elevator is in stop mode or disconnect with IED/ Elevator lock mode
Elevator failure or communication abnormality
Elevator is under inspection

External display board parameters

Paramete	Name of the parameter	Default value	Parameter range	
08-38	Disable external display board	0	O: Car-top board is valid, external display board is valid 1: Car-top board is valid, external display board is invalid 2: Car-top board is invalid, external display board is valid 3: Car-top board is invalid, external display board is invalid	
08-39	Disable door open	0	0: Door open is enabled 1: Door open is disabled	

The communication interface is configured by the parameter 08-38.

When the parameter 08-38 is set as 0,

external display board communication and car-top board communication are valid.

When the parameter 08-38 is set as 1,

car-top board communication is valid but the external display board communication is invalid.

When the parameter 08-38 is set as 2,

car-top board communication is invalid but external display board communication is valid.

When the parameter 08-38 is set as 3,

both external display board communication and car-top bard communication are valid.

Return to the base station, fire, elevator lock

Parameter	Name of the parameter	Default value		Parameter range	
08-02	Elevator base station	1	Floor 1 ~ 47		
08-03	Fire base station	1	Floor 1 ~ 47		
08-04	Elevator lock base station	1	Floor 1 ~ 47		

Floor indication

Please refer to the description of terminals of Encode EMED-PGHSD

Parameter	Name of the parameter	Default value	Parameter range
05-00	Physical floor 1 indication	1	0~9999
05-01	Physical floor 2 indication	2	, UN C'
05-02	Physical floor 3 indication	3	Settings: XX YY
05-03	Physical floor 4 indication	4	Settings. AX 11
05-04	Physical floor 5 indication	5	XX: Tens digit
05-05	Physical floor 6 indication	6	YY: Units digit
05-06	Physical floor 7 indication	7	11. Offits digit
05-07	Physical floor 8 indication	8	
05-08	Physical floor 9 indication	9	00='0'
05-09	Physical floor 10 indication	100	01='1'
05-10	Physical floor 11 indication	101	00_101
05-11	Physical floor 12 indication	102	02='2'
05-12	Physical floor 13 indication	103	03='3'
05-13	Physical floor 14 indication	104	04='4'
05-14	Physical floor 15 indication	105	, O' , O' , M'
05-15	Physical floor 16 indication	106	05='5'
05-16	Physical floor 17 indication	107	06='6'
05-17	Physical floor 18 indication	108	
05-18	Physical floor 19 indication	109	07='7'

05-19	Physical floor 20 indication	200	08='8'
05-20	Physical floor 21 indication	201	
05-21	Physical floor 22 indication	202	09='9'
05-22	Physical floor 23 indication	203	10='A'
05-23	Physical floor 24 indication	204	44 (D)
05-24	Physical floor 25 indication	205	11='B'
05-25	Physical floor 26 indication	206	12='G'
05-26	Physical floor 27 indication	207	13='H'
05-27	Physical floor 28 indication	208	
05-28	Physical floor 29 indication	209	14='L'
05-29	Physical floor 30 indication	300	15='M'
05-30	Physical floor 31 indication	301	
05-31	Physical floor 32 indication	302	16='P'
05-32	Physical floor 33 indication	303	17='R'
05-33	Physical floor 34 indication	304	. (3)
05-34	Physical floor 35 indication	305	18='-'
05-35	Physical floor 36 indication	306	19="
05-36	Physical floor 37 indication	307	20='X'
05-37	Physical floor 38 indication	308	20= X
05-38	Physical floor 39 indication	309	21=up_icon
05-39	Physical floor 40 indication	400	22=down_icon
05-40	Physical floor 41 indication	401	22-down_lcon
05-41	Physical floor 42 indication	402	
05-42	Physical floor 43 indication	403	
05-43	Physical floor 44 indication	404	7/1 'O. V
05-44	Physical floor 45 indication	405	" C)
05-45	Physical floor 46 indication	406	
05-46	Physical floor 47 indication	407	" C. "V. "

Encode EMED-PGHSD

※ Please refer to Figure D1-15

Parameter	Name of the parameter	Default value	Parameter range
02-07	Encoder type selection	0	0: No function 1: ABZ 2: ABZ + Hall 3: SIN/COS + Sinusoidal 4: SIN/COS + Endat 5: SIN/COS 6: SIN/COS + Hiperface
	Number of pulses for each turn of the encoder	600	1~25000
02-09	Encoder's input type setting		 0: No function 1: Phases A/B are pulse inputs: Phase A is 90 degree leading Phase B with forward rotation 2: Phases A/B are pulse inputs: Phase B is 90 degree leading Phase A with forward rotation 3: Phase A is a pulse input; Phase B is the direction input: L is reverse direction and H is forward direction 4: Phase A is a pulse input; Phase B is the direction input: L is forward direction and H is reverse direction 5: Single phase input

Function of sinusoidal type ENCODER

J3 (refer to F	igure D1-10)	Heidenhair	n ERN1387	The The	
◎ 10 9 (3) (2) (1) (8) (7) (6) (9) (3) (2) (11)	1 2 3 4	• • • B • • • A 5 6 7	Heidenhain ECN1313 (EnDat)	
Terminal No.	Name of the terminal	Terminal No.	Name of the terminal	Name of the terminal	
1	B-	5a	B-	B-	
2	NC	NC	NC	0V	
3	Z+	4b	R+	0V	
4	Z-	4a	R-	0V	
5	A+	6b	A+	A+	
6	A-	2a	A-	A-	
7	0V	5b	0V	0V	
8	B+	3b	B+	B+	
9	+5V	1b	UP	VP	
*10	SIN	7b	C+	Data-	
*11	SIN'	1a	C-	Data+	
12	cos	2b	D+	CLOCK+	
13	COS'	6a	D-	CLOCK-	
14	NC	-	2.G-	VP	
15	NC	-	-	0V	

[☆] For more information about the encoder, please refer to Appendix B B-5-2

[※] EMED-PGHSD J3 supports two connection configurations; in the Table shown above, the assignments of Terminals 10 and 11 are different; when the parameter 02-12 is set as 0000h, the information shown in the table shown above are valid; when the parameter 02-12 is set as 0004h, Terminal No. 10=C- and Terminal No. 11=C+.

Motor Tuning

Enter the data shown on the motor nameplate

		Default			
Parameter	Name of the parameter	value	Parameter range		
01-02	Control method	0	0: V/F control 1: V/F control + Encoder (VFPG) 2: Sensorless vector control (SVC) 3: FOC vector control + Encoder (FOCPG) 4: Torque control + Encoder (TQCPG) 8: FOC PM control (FOCPM)		
01-04	Elevator speed	1.00	0.10 ~ 4.00 m/s		
01-05	Maximum Output Frequency	60.00/ 50.00			
02-00	Motor Auto Tuning	0	0: No function 1: Rolling test 2: Static test		
02-01	Full-load Current OF Motor	#.##	(30 ~ 120%) * the model's rated current (Amps)		
02-02	Rated power of Motor	#.##	0.00 ~ 655.35kW		
02-03	Rated speed of Motor (rpm)	1710	0~65535		
02-04	Numbers of Motor poles	4	2~96		
	Angle between Magnetic Pole and PG Origin	360.0	0.0~360.0°		
02-06	Output Direction Selection	0	Same as the configured direction Opposite to the configured direction		
02-07	Encoder type selection	0	0: No function 1: ABZ 2: ABZ + Hall 3: SIN/COS + Sinusoidal 4: SIN/COS + Endat 5: SIN/COS 6: SIN/COS + Hiperface		
02-08	Encoder pulses	0	1~25000		
02-09	Encoder Input type setting	600	 0: No function 1: Phases A/B are pulse trains: Phase A is 90 degree leading Phase with forward rotation 2: Phases A/B are pulse trains: Phase B is 90 degree leading Phase with forward rotation 3: Phase A is a pulse train; Phase B is the direction sign: L is reverse an H is forward 4: Phase A is a pulse train; Phase B is the direction sign: L is forward an H is reverse 5: Single phase input 		
	U, V, W input mode selection	0	O: Z signal is at the falling edge of Phase U 1: Z signal is at the leading edge of Phase U		
	Rated frequency of Motor	60.00/ 50.00	0.00 ~ 400.00Hz		
02-12	Rated voltage of Motor	220.0 440.0	230V Series: 0.0V ~ 255.0V 460V Series: 0.0V ~ 510.0V		
	Stator Resistance (Rs) of Motor	0.000	0.000~65.535Ω		
	Stator Inductance (Lx) of Motor	0.0	0.0~6553.5mH		
02-18	Back Electromotive Force	0.0	0.0~6553.5Vrms		
	Inspection speed	0.08	0.10 ~ 4.00m/s		

Synchronous Motor (PM)

It is recommended to allow the motor self-learn before engaging the steel wire rope. When the U V W phase sequence of a synchronous motor is changed, the encoder is replaced, or the encoder wiring is changed, it is necessary to recognize the encoder position angle again.

Tuning process of a synchronous motor without load:

The first set parameters are usually used for test in the factory before delivery, so it is necessary to execute the tuning process for both the control cabinet and the motor at the same time. Before the test is executed, please make sure the wiring of the contracting brake, the wiring of the output relay, and the settings of the control parameters are correct.

- Enter the following parameters
 - 01-05, 02-01~02-04, 02-11, 02-12
- Parameters for the encoder

02-07~02-10

Control method: 01-02=8

- Please make sure that the traction wheel is not hanging with any elevator car or load.
- Set 02-00=1 for self-tuning without load. Use the inspection terminals to execute the self-learning control. Press the inspection Up or Down buttons on the control panel. When the message "TUNE" is shown on the panel, execute the following two consecutive operations:
 - (1) At the same time, the contracting brake is not activated, the output relay is switched on for motor self-learning. The motor's parameters are automatically written in 02-14, 02-17, and 02-18.
 - (2) After a few seconds, the contracting brake opens, the motor is rotating, and the encoder self-learning starts. The parameter values obtained from the tuning process will be automatically written in 02-05 for the encoder's origin offset angle.
- After the tuning process is complete, please set 6-11= inspection speed, open the contracting brake, and run the motor without load to check if the operating current is extraordinarily large and if the motor is running normally. For any error, execute the self-tuning process again or modify 02-09 before executing the self-tuning again.
- * After the self-tuning process is complete, please recover the terminal status.

Caution:

- 1) During the self-learning process of the encoder, if "PGF2" failure message occurs, please modify the parameter 02-09 (for example: if it is originally 1, you can change it to 2) before executing the motor self-tuning process again.
- 2) During the learning process of the encoder, set the inspection direction be opposite to the actual operation direction, you can set parameters 02-06 to 1 to correct this problem without exchange the output wires for the motor.

Tuning process of a synchronous motor with load:

Usually, the load is the elevator car that is hanging in the hoistway, so the motor is not able to be separated from the load. Therefore, the motor tuning process is usually executed by the **inspection control** mode. Before the test is executed, please make sure the wiring of the contracting brake, the wiring of the output relay, and the settings of the control parameters are correct.

- Make sure that the elevator is in the inspection mode.
- Enter the following parameters 01-05, 02-01~02-04, 02-11, 02-12
- Parameters for the encoder

02-07~02-10

Control method: 01-02=8

- Please make sure the directions of the upward and downward movement when the traction wheel is hanging with the elevator car for operation.
- ※ Set 02-00=2 for self-tuning with load. Use the inspection terminals to execute the self-learning control.

 Press the inspection Up or Down buttons on the control panel. When the message "TUNE" is shown on the panel, execute the following two consecutive operations:
 - (1) In the beginning, the contracting brake is not activated, the output relay is switched on for motor self-learning. The obtained motor's parameters are automatically written in 02-14, 02-17, and 02-18.
 - (2) After a few seconds, the contracting brake opens and the motor is rotating for 3 turns to execute the encoder self-learning process. The parameter values obtained from the tuning process will be automatically written in Parameter 02-05 for the offset angle of the encoder's origin.
- After the tuning process is complete, please set 6-11= inspection speed, open the contracting brake, and run the motor with empty car to check if the operating current is extraordinarily large and it the motor is running normally. For any error, execute the self-tuning process again or modify 02-09 before executing the self-tuning again.
- * After the self-tuning is complete, the elevator is still in the inspection mode waiting for inspection run to inspect the activation timing of the hoistway signals.

Caution:

- If the tuning is not successful, the risk of elevator sudden fall may occur. It is recommended to execute the operation by two persons together: One presses the inspection button, the other handles the emergency stop button so as to shut off the power in time in case the elevator sudden fall occurs.
- Moring the self-learning process of the encoder, if "PGF2" failure message occurs, please modify the parameter 02-09 (for example: if it is originally 1, you can change it to 2) before executing the motor self-tuning process again.
- During the learning process of the encoder, set the inspection direction be opposite to the actual operation direction, you can set parameters 02-06 to 1 to correct this problem without exchange the output wires for the motor.
- * The deviation angle obtained from the encoder self-learning process with load may have some bias. It is recommended to execute the learning process twice both for the upward and downward movements and then take their average value.

Asynchronous Induction Motor (IM)

Select the control mode: When the IM motor is used by the customer, please set the parameter 01-02=3

Parameter 0: V/F control
01-02 1: V/F control + Encoder (VFPG)
Contents 2: Sensorless vector control (SVC)
3: FOC vector control + Encoder (FOCPG)
4: Torque control + Encoder (TQCPG)
8: FOC PM control (FOCPM)

NOTE: Configure the parameter settings according to the motor type (PM or IM) used by the customer

Motor parameter automatic measurement

Motor Auto Tuning

Parameter 0: No function
02-00 1: Rolling test
Contents 2: Static testing

NOTE: The automatic measurement process does not need to release the brake. If a solenoid valve is installed between the driver and the motor, it is necessary to energize the solenoid valve. For the static measurement with a setting range of 2, it is necessary to enter the motor 02-13. During the automatic measurement, the digital operating panel may show the warning message "Auto tuning" till the measurement is complete. Then the panel may stop displaying the warning message and store the measurement result into parameters 02-14~02-17 •

NOTE: The automatic measurement for IM motor can also provide dynamic measurement.

Full-load current of Motor

Parameter (30 ~ 120%) * the model's rated current (Amps)
02-01
Contents

Rated power of Motor

Rated speed of Motor (rpm)

Parameter Contents
02-03 0~65535

Numbers of Motor Poles

Parameter Contents
02-04 2~96

"IM motor does not need the origin deviation measurement because the magnetic pole positioning is not required for an IM motor."

Hoistway self-learning

Please confirm the following conditions before executing the hoistway self-learning:

- (1) Make sure that the elevator satisfies the inspection running condition
 - IED and the Car-top board: The IED and the car-top board communicate with each other through the CAN communication. If the communication is not normal, the IED may exert error messages.
 - IED and External display board: The IED and the External display board communicate with each other through the MODBUS communication based on the address configured by parameters 08-00 and 08-01. If the communication is not normal, the parameters 00-54~00-56 may show the addresses with communication time-outs. If the communication is normal, the contents of 00-54~00-56 will be 0.
- (2) Make sure that the settings for the lowest and highest elevator floors (08-00~08-01) are configured and the corresponding values are correct. In addition, the settings for the lowest and highest floors must match the physical floors.
- (3) Make sure that the elevator can move to any target floor correctly. If the settings are incorrect, the hoistway self-learning process may have errors.
- (4) Check the hoistway signals 00-15~00-17.
 In the inspection mode, execute the inspection operation can check the time sequence of the hoistway signals (upper/lower limits, upward/ downward forced deceleration, upper/lower leveling or the door area signal) are correct so as to ensure that the hoistway self-learning process can be completed normally.
- (5) Configure the movement speed and the system control method 06-10~06-13

When the hoistway self-learning starts, the elevator moves downwards at the inspection speed (06-11) to search for the position of the lower limit. After triggering downward 1st level forced deceleration switch, it keeps moving downwards at the leveling speed (06-12) to continue searching for the position of the lower limit. When the lower limit signal is triggered, it will move upwards at the floor search speed (06-10) to start the hoistway self-learning process; once it triggers upper 1st level forced deceleration switch, it will move upward at the leveling speed (06-12) to continue to search for the upper limit. After the upper limit is triggered, it moves at the operation speed (06-13) back to the 1st floor to execute the hoistway position confirmation again. After the movement stops, the hoistway self-learning is complete. It is recommended that the running speed 06-13 shall be set as half of the maximum speed of the elevator for the hoistway self-learning.

- (6) The hoistway self-learning process is executed as follows:
 - A Make sure that the elevator is in the inspection mode
 - B Set the parameter 08-50 as 1
 - C Switch back to the normal mode, i.e., the automatic hoistway self-learning command
- (7) When the system executes the hoistway self-learning command automatically, it will move downward at the inspection speed to search for the position of the lower limit, and then move upward to start the self-learning

process. After the self-learning process is complete, it will move fast back and level with the lowest floor. (The elevator will execute the hoistway signal self-learning according to the aforementioned sequence, and automatically set 08-50 as 0 after the learning process is complete. During the hoistway self-learning, if it is required to stop the process, manually set 08-50 as 0 so as to stop the elevator and enter the inspection state.)

Methods for interrupting self-learning:

A Switch back to the inspection mode

B Abnormal error message is generated

C While the hoistway self-learning command is executed, the parameter is set as 08-50=1 again.

(8) Check the hoistway parameters 04-00~04-95 and parameters 06-23~06-38.

After the hoistway self-learning is complete, check if the absolute position of the floors corresponding to the hoistway parameter 04-00~04-95 are reasonable. It is allowed to use the inspection movement to move the elevator to each floor to check if the absolute positions match the hoistway parameters.

- (9) Set the floor indications 05-00~05-46
 - Set the floor indications 05-00~05-46 properly according to the elevator's operation environment. Refer to the description of 05-00~05-46 for the configuration detail.
- (10) Definition of upper/lower leveling: When the elevator is moving downward, the lower leveling signal is triggered first. When the elevator is moving upward, the upper leveling signal is triggered first.
- (11) When the elevator moves downward and level with the lowest floor and continues moving down, the lower leveling signal must be released before the lower limit signal is triggered. In this case, the upper leveling signal must always be valid.
- (12) When the elevator moves upward and level with the highest floor and continues moving up, the upper leveling signal must be released before the upper limit signal is triggered. In this case, the lower leveling signal must always be valid.
- (13) Make sure that the coercionary deceleration distance and the upper/lower limits are correctly installed.
- (14) If the position of the leveling plate is re-adjusted, it is necessary to execute the hoistway self-learning process again.
- The parameters 04-02 ~ 04-95 correspond to the upper/lower leveling for the floors 1 ~ 47. For a more detailed list of these parameters, please refer to Summary of Parameters.

×

Paramete	Name of the parameter	Default value	Parameter range
01-04	Elevator speed	1.00	0.10 ~ 4.00 m/s
08-00	Elevator's topmost floor	5	Floor 1 ~ 47
08-01	Elevator's down-most floor	1	Floor 1 ~ 47
08-02	Elevator base station	1	Floor 1 ~ 47
08-50	Hoistway self-learning	0	Stop hoistway self-learning Start hoistway self-learning
06-11	Inspection speed	0.08	0.10 ~ 4.00m/s
06-12	Leveling speed	0.15	0.10 ~ 4.00m/s
06-23	Position of lower limit - high	0	0 ~ 9999m
06-24	Position of lower limit - low	0.0	0.0 ~ 999.9mm
	Downward 1 st level forced deceleration position - high	0	0 ~ 9999m
06-26	Downward 1 st level forced deceleration position - low	0.0	0.0 ~ 999.9mm

06-27	Downward 2 nd level forced deceleration position - high	0	0 ~ 9999m	10° 10' 10'
06-28	Downward 2 nd level forced deceleration position - low	0.0	0.0 ~ 999.9mm	
04-00	Landing board length	0.0	0.0 ~ 999.9mm	.0
04-01	Distance between upper and lower leveling signals	0.0	0.0 ~ 999.9mm	
04-02	Floor 1 position - high	0	0 ~ 9999m	
04-03	Floor 1 position - low	0.0	0.0 ~ 999.9mm	
04-04	Floor 2 position - high	0	0 ~ 9999m	
04-05	Floor 2 position - low	0.0	0.0 ~ 999.9mm	
~	~	~	~	
04-94	Floor 47 position - high	0	0 ~ 9999m	
04-95	Floor 47 position - low	0.0	0.0 ~ 999.9mm	

Fast car test run

Car's internal command test

Set the elevator in the automatic mode. Configure the parameter 08-34 by using the small keypad function menu to enter the single-floor command to check if the elevator is running according to the command.

Hall call command test

Set the elevator in the automatic mode. Configure the parameter 08-35 and 08-36 by using the small keypad function menu to enter the hall call up/down movement or execute the hall call command for each floor to check if the elevator is running according to the commands.

Door open/close function test

When the elevator reach the station at the leveling position, check if the door opens normally and the door open hold time meets the requirement: When the elevator responds to the call and starts to move, check if the door closes normally.

	•				
Paramete	r Name of the parameter	Default value	.10	Parameter range	
08-34	Test floor 1	0	Floor 1 ~ 47		
08-35	Test floor 2	0	Floor 1 ~ 47		
08-36	Test floor 3	0	Floor 1 ~ 47	.0	

Fast car movement

After the fast car test run is complete correctly, set the elevator in the inspection state, configure or add the required functions, and then starts the commissioning of fast car movement.

- Configure 08-48 and 08-49 according to the customer's actual on-site demands.
- According to the actual on-site conditions, adjust the parameter group 08, configure the base station, fire, elevator lock base station (08-02 ~ 08-04) and service floor (08-05 ~ 08-07), group selection method, time-sharing services, and parallel peak control.
- Safety circuit test

If any safety switch is activated, the safety circuit relay will release.

Door lock circuit test

If any hall door lock or car door lock is unlocked, the door lock relay is released.

Contracting brake contactor sticking test

While parking, the top-pressure contracting brake contactor should be protected by the system

Output contactor sticking test

While parking, the top-pressure output contactor should be protected by the system

Slipping protection function test

Move the elevator to the middle floor in the inspection mode. Remove the system leveling signal wires (to set the signal normally open) and then switch to the automatic mode, the elevator will find leveling at a low speed. Within 45 seconds, the system automatic protection is activated.

Elevator lock function test

- (1) If the elevator parks at a certain floor other than the base station, the elevator lock base station's elevator lock signal is triggered and the elevator door shall immediately close and not respond to any hall call. It will move fast back to the elevator lock base station. After the car stops, the door opens for a delay time and then the door closes and the light goes out. All the commands and hall calls are shut off, and the hall external displays go off.
- (2) If the elevator is running and the elevator lock base station's elevator lock signal is triggered, all the hall call commands will disappear. After the elevator responds to all the command one by one, it will not respond to any hall call but move fast back to the elevator lock base station. As the car stops and the door opens, the door closes after a time delay, the indicator goes off, all the commands and hall calls are shut off, and the hall external displays go off.
- (3) If the elevator parks at the elevator lock base station, after the base station's elevator lock signal is triggered, the elevator shall open the door and then close the door, turn off the light, shut off all the commands and hall calls, and turn off the hall displays. But the car's internal Door Open indicator is constantly lit.

Parameter	Name of the parameter	Default value (NO)	9	Parai	meter range		
08-02	Elevator base station	1	Floor 1 ~ 47				
08-03	Fire base station	1	Floor 1 ~ 47				
08-04	Elevator lock base station	1	Floor 1 ~ 47				
08-05	Service floor 1	FFFF	0~FFFF) `	30	
08-06	Service floor 2	FFFF	0~FFFF				
08-07	Service floor 3	FFFF	0~FFFF				
08-48	Factory function 1	0	0~65535				
08-49	Factory function 2	0	0~65535	- N-			

Comfort adjustment

The comfort during the elevator's movement can be adjusted through the parameter group 06 so as to allow the elevator to provide a comfortable and smooth movement; however, the comfort of an elevator is influenced by various factors, for example, improper mechanical adjustments or parameter settings may lead to bad comfort during the elevator movement.

The mechanical factors that affect the comfort can be categorized in to several conditions listed below:

- (1) The surface smoothness of the elevator's guide rails, verticality of the installed guide rails, and the treatment of the joints between rails.
 - ☑ The verticality of the guide rails can affect not only the elevator's horizontal vibration but also its vertical vibration during movement.
 - ☑ If the joints between guide rails are not properly handled, the step-like motion at certain position may occur during the elevator's movement.

- (2) Tightness of guide shoes
 - If the guide shoes are too tight, the step-like motion may occur as the elevator starts to move; meanwhile, the sudden braking motion may occur as the elevator is going to stop; if the guide shoes are too loose, the vibration may occur during the elevator's movement.
- (3) The gap between the mechanical contracting brakes of the motor has great effect on the movement during starting and braking.
- (4) The imbalance between the tensions of the elevator's steel wire ropes is usually the origin of the vibration of the elevator.
- (5) Whether the mechanical vibrations-reduction rubber pads are employed in the elevator car or the traction motor is important as well.

The electrical related parameters also have effects on the comfort. Improper settings may cause vibration in the vertical direction.

(1) The motor related parameters 02-00 ~ 02-17 are the parameters mainly used by the system for controlling the motor. Incorrect motor type selection, incorrect parameter settings, or inaccurate self-learning results may cause motor's vibration or noise which in turn may affect the comfort.

Parameter	Name of the parameter	Default value	Parameter range
02-00	Motor Auto Tuning	0	0: No function 1: Rolling test 2: Static test
02-01	Full-load Current of Motor	#.##	(30 ~ 120%) * the model's rated current (Amps)
02-02	Rated power of Motor	#.##	0.00 ~ 655.35kW
02-03	Rated speed of Motor (rpm)	1710	0~65535
02-04	Number of Motor Poles	4	2~96
02-05	Angle between Magnetic Pole and PG Origin	360.0	0.0~360.0°
02-06	Output Direction Selection	0	Same as the configured direction Opposite to the configured direction
02-07	Encoder type selection	0	0: No function 1: ABZ 2: ABZ + Hall 3: SIN/COS + Sinusoidal 4: SIN/COS + Endat 5: SIN/COS 6: SIN/COS + Hiperface
02-08	Encoder Pulse	600	1~25000
02-09	Encoder's input type setting	0	 0: No function 1: Phases A/B are pulse inputs: Phase A is 90 degree leading Phase B with forward rotation 2: Phases A/B are pulse inputs: Phase B is 90 degree leading Phase A with forward rotation 3: Phase A is a pulse input; Phase B is the direction input: L is reverse direction and H is forward direction 4: Phase A is a pulse input; Phase B is the direction input: L is forward direction and H is reverse direction and H is reverse direction

02-10	U, V, W input mode selection	0	0: Z signal is at the falling edge of Phase U 1: Z signal is at the leading edge of Phase U
02-11	Rated frequency of Motor	60.00/ 50.00	0.00 ~ 400.00Hz
02-12	Rated voltage of Motor	220.0 440.0	230V Series: 0.0V ~ 255.0V 460V Series: 0.0V ~ 510.0V
02-13	No-load current of Motor	#.##	0 ~ Motor's full load current (Parameter 02-01) setting
02-14	Stator Resistance (Rs) of Motor	0.000	0.000~65.535Ω
02-15	Rotor Resistance (Rr) of Motor	0.000	0.000~65.535Ω
02-16	Magnetizing Inductance (Lm) of Motor	0.0	0.0~6553.5mH
02-17	Stator Inductance (Lx) of Motor	0.0	0.0~6553.5mH

(2) The parameters 06-03 and 06-04 are the acceleration times for the rapid acceleration at starting section S1 and the rapid acceleration at the ending section S2 of the S curve movement. If the times are too short, vibrations may occur at the corresponding sections. The acceleration time for S2 may be increased properly.

Paramete	Name of the parameter	Default		Parameter range	
		value			
06-03	S-curve for Acceleration	1.00	0.00 ~ 25.00 seconds		
	Departure Time S1				
06-04	S-curve for Acceleration	1.00	0.00 ~ 25.00 seconds		
3	Arrival Time S2				

(3) The parameters 06-05 and 06-06 are the deceleration times for the rapid deceleration at starting section S3 and the rapid deceleration at the ending section S4 of the S curve movement. If the times are too short, vibrations may occur at the corresponding sections. The deceleration time for S4 may be increased properly.

Paramete	Name of the parameter	Default	Parameter rai	nge
		value		
	S-curve for Deceleration Departure Time S3	2.50	0.30 ~ 4.00 seconds	30
	S-curve for Deceleration Arrival Time S4	2.50	0.30 ~ 4.00 seconds	

(4) Adjustment at startup

Parameter	Name of the parameter	Default value	· · ·	Parameter range
	Brake Release Delay Time when Elevator Starts	0.250	0.000 ~ 65.000 seconds	. 18
	Turn On Delay of Magnetic Contactor between Drive and Motor	0.200	0.000 ~ 65.000 seconds	HANN. O'ILL'S
	Turn Off Delay of Magnetic Contactor between Drive and Motor	0.200	0.000 ~ 65.000 seconds	WAN THE
06-20	DC brake time at startup	0.0	0.0 ~ 60.0 seconds	
07-01	Zero-speed bandwidth	10	0 ~ 40Hz	
07-05	Zero-speed ASR P gain	100.0	0.0~500.0%	-C
	Operation Time of Zero Speed	0.250	0.000 ~ 65.535 seconds	
07-24	Zero Speed Gain (P)	80.00	0~655.00%	
	Low-pass filtering time at the starting position	0.004	0.000 ~ 65.535 seconds	a.cr

At startup, the elevator may exhibit distinct vibrations. Adjust the mechanical brake release delay time 06-15 and the opening time for the contracting brake. Meanwhile, it is necessary to adjust the DC actuation time at startup and the PI value at startup so as to prevent the elevator from sudden falling.

(5) Adjustment for ordinary movement

Paramete	Name of the parameter	Default value	Parameter range
06-01	Deceleration	0.50	0.00 ~ 2.00m/s ²
06-02	Forced deceleration	0.50	0.00 ~ 2.00m/s ²
06-04	S-curve for Acceleration Arrival Time S2	1.00	0.00 ~ 25.00 seconds
06-05	S-curve for Deceleration Departure Time S3	2.50	0.30 ~ 4.00 seconds
06-06	S-curve for Deceleration Arrival Time S4	2.50	0.30 ~ 4.00 seconds
06-07	Landing deceleration	10.00	0.00 ~ 20.00m/s ²
07-00	Inertia Ratio	40	1~300%
07-01	Zero-speed bandwidth	10	0 ~ 40Hz
07-02	Low-speed bandwidth	10	0 ~ 40Hz
07-03	High-speed bandwidth	10	0 ~ 40Hz
07-04	Zero-speed bandwidth at parking	10	0 ~ 40Hz
07-05	Zero-speed ASR P gain	100.0	0.0~500.0%
07-06	Zero-speed ASR integration time I	0.100	0.000 ~ 10.000 seconds
07-07	ASR P1 gain	100.0	0.0~500.0%
07-08	ASR integration time I1	0.100	0.000 ~ 10.000 seconds
07-09	ASR P2 gain	100.0	0.0~500.0%
07-10	ASR integration time I2	0.100	0.000 ~ 10.000 seconds

If a weightlessness feeling occurs during the elevator's movement, the acceleration/deceleration time can be increased properly; if the transition from low speed to high speed or from high speed to low speed seems too rush, the corresponding times in the S curve can be modified; if vibrations always occur during normal movement, the low-speed bandwidth, high-speed bandwidth, mechanical inertia percentage and corresponding PI can be adjusted.

(6) Adjustment at stop

Parameter	Name of the parameter	Default value	Parameter range
06-07	Landing deceleration	10.00	$0.00 \sim 20.00 \text{m/s}^2$
06-21	DC brake time at stop	0.0	0.0 ~ 60.0 seconds
06-39	Distance margin for landing deceleration	100.0	0.0 ~ 6000.0mm
07-11	Zero-speed ASR P gain at landing	100.0	0.0~500.0%
07-12	Zero-speed ASR integration time I at landing	0.100	0.000 ~ 10.000 seconds
07-26	Direct landing position control P gain	10.00	0.0~655.00 %
07-27	Low pass filter time for direct landing position control	0.018	0 ~ 1.000 seconds

If vibrations occur at stop, in addition to the parameters listed above, the crawling speed and crawling distance can be adjusted as well (it is recommended that the leveling time shall not exceed 4 seconds).

(7) Leveling position correction

Paramete	Name of the parameter	Default	160	Parameter range	
		value	767.		
04-00	Landing board length	0.0	0.0 ~ 999.9mm		
04-01	Distance between upper	0.0	0.0 ~ 999.9mm		
	and lower leveling signals				

Landing board length 04-00: (mm) the value obtained from the self-learning process

Spacing between the upper and lower leveling signals 04-01: (mm) the value obtained from the self-learning process

Fine-tuning of these two parameters can correct the distance between the elevator's car and the leveling height.

4 Group Control

Basic Parameter

Related parameters setting for group control:

Parameter	Function of parameter	Default value	Range
	Number of elevators for group control	1	1~8
118-119	Elevator No. in group control	1	1~8
08-10	Group control selection	0	b0=1 : Group control enable

- (1) The number of elevators for group control can be set in 08-08; 08-09 is to give serial number for the elevators in the group. The elevator is Master when 08-09 is set 1.
- * The numbers given to group controlled elevators must be continuous series. For example, four elevators are for group control, and their number must be 1, 2, 3, 4. If they are given 1, 3, 5, 7, then the group control can not be used.
- (2) Group control function will be enabled when 08-10 bit set as 1.

5 Summary of Parameters

00 Parameters for display

★ The parameter can be set during operation

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
00-00	Speed command	Read only	1		0	0	0	0	0	0
00-01	Output speed	Read only	,		0	0	0	0	0	0
00-02	VBUS voltage	Read only	,		0	0	0	0	0	0
00-03	Output current	Read only			0	0	0	0	0	0
00-04	Output voltage	Read only			0	0	0	0	0	0
00-05	Power factor angle	Read only			0	0	0	0	0	0
00-06	Output power	Read only			0	0	0	0	0	0
00-07	Reserved	42								1
00-08	Motor speed	Read only	,		0	0	0	0	0	0
00-09	Output torque	Read only	,		0	0	0	0	0	0
00-10	PG feedback	Read only			0	0	0	0	0	0
00-11	Display the IED output electrical	Read only			0	0	0	0	0	0
	angle					1				
00-12	AVI(%)	Read only			0	0	0	0	0	0
00-13	Rectifier/power capacitor temperature	Read only		.00	0	0	0	0	0	0
00-14	Power module IGBT temperature	Read only			0	0	0	0	0	0
00-15	Status of IED input terminals MI1~MI16	Read only			0	0	0	0	0	0
00-16	Status of IED input terminals MI17~MI24	Read only			0	0	0	0	0	0
00-17	Status of IED input terminals MI26~MI36	Read only	,		0	0	0	0	0	0
00-18	Status of IED output terminals RY1~RY16	Read only	, d		0	0	0	0	0	0
00-19	Multi-stage speed status	0 : Zero speed 1 : Reserved 2 : Hoistway self-learned speed 3 : Inspection speed 4 : Reverse leveling speed 5 : Fast car speed 6 : Rescue speed	JO. III	P.III.C	0	0	0	0	0	0
00-20	IED driving status	b5: Hidden the parameter display b10: Command source b11: Parameter lock display Others: Reserved	nun.		0	0	0	0	0	0
00-21	IED internal error code	Read only	<u> </u>			0	0	0	0	0
00-22	IED warning code	Read only			0	0	0	0	0	0
00-23	Car status 1	b0: Up-going b1: Down-going b2: Landing b3: Stop b4: Front door open b5: Front door close	M.cr.	1	0	0	0	0	0	0

Parameter code	Function of the parameter	Parameter range	level Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	NAMA TAMATA	b8: Reserved b9: Reserved b10: Reserved b11: Front door opening delay b12: Light output display b13: Fan output display b14: Buzzer output display b15: Reserved	JP IIII	3				>	18
00-24	Car status 2	b0: Inspection up-going b1: Inspection down-going b2: Front door close display b3: Reserved b4: Reserved b5: Reserved b6: Full load b7: Door lock bypass feedback	R.C. WWW	0	0	0	0	0	0
July 1	M. J. J. M. J. D. J.	b8: Reserved b9: Reserved b10: Reserved b11: Reserved b12: Rear door open b13: Rear door close b14: Rear door opening delay b15: Reserved							
00-25	Operation mode	b0: Normal mode b1: Inspection mode b2: Elevator lock mode b3: Error occurs b4: Operator mode b5: VIP mode b6: Fire emergency landing mode	MANHIN	0	0	0	0	0	0
indi.il		b7: (1st level) Fire rescue mode b8: Twins control mode b9: Group control mode b10: Hoistway self-learning mode b11: Re-positioning b12: Leveling finding b13: Independent mode b14: Elevator jogging b15: Emergency power mode		S					
00-26	Elevator door status	b0: Front door open output display b1: Front door close output display b2: Front door motor reset display b3: Front door slow operation output dis b4: Rear door open output display b5: Rear door close output display b6: Rear door motor reset display	Wille.	0	0	0	0	0	0
A LIP HE	in the state of th	b7: Rear door slow operation output dispose in the second of the second	Juay						
	In-car display board floor command 1 (Floor 1 ~ 16)	Read only	% C)	0	0	0	0	0	0

									R	
Parameter code	Function of the parameter	Parameter range	level	Default value	ΥF	VFPG	SVC	FOCPG	TQCPG	FOCPM
00-28	In-car display board floor command 2 (Floor 17 ~ 32)	Read only		A.C	0	0	0	0	0	0
00-29	In-car display board floor command 3 (Floor 33 ~ 48)	Read only			0	0	0	0	0	0
00-30	In-car display board floor display 1 (Floor 1 ~ 16)	Read only			0	0	0	0	0	0
00-31	In-car display board floor display 2 (Floor 17 ~ 32)	Read only	11/1		0	0	0	0	0	0
00-32	In-car display board floor display 3 (Floor 33 ~ 48)	Read only			0	0	0	0	0	0
00-33	In-car display board up-going command 1 (Floor 1 ~ 16)	Read only		A.	0	0	0	0	0	0
00-34	In-car display board up-going command 2 (Floor 17 ~ 32)	Read only			0	0	0	0	0	0
00-35	In-car display board up-going command 3 (Floor 33 ~ 48)	Read only			0	0	0	0	0	0
00-36	External display board up-going display 1 (Floor 1 ~ 16)	Read only			0	0	0	0	0	0
00-37	External display board up-going display 2 (Floor 17 ~ 32)	Read only			0	0	0 <	0	0	0
00-38	External display board up-going display 3 (Floor 33 ~ 48)	Read only	.00		0	0	0	0	0	0
00-39	In-car display board down-going command 1 (Floor 1 ~ 16)	Read only			0	0	0	0	0	0
00-40	In-car display board down-going command 2 (Floor 17 ~ 32)	Read only		100	0	0	0	0	0	0
00-41	In-car display board down-going command 3 (Floor 33 ~ 48)	Read only			0	0	0	0	0	0
00-42	External display board down-going display 1 (Floor 1 ~ 16)	Read only			0	0	0	0	0	0
00-43	External display board down-going display 2 (Floor 17 ~ 32)	Read only			0	0	0	0	0	0
00-44	External display board down-going display 3 (Floor 33 ~ 48)	Read only			0	0	0	0	0	0
00-45	Current floor	Read only			0	0	0	0	0	0
00-46	Current position (0.1mm)	Read only			0	0	0	0	0	0
00-47	Current position (1m)	Read only			0	0	0	0	0	0
00-48	Elevator error code	Read only			0	0	0	0	0	0
00-49	Weighting compensation input value	Read only			0	0	0	0	0	0
00-50	Car-top board input terminal MI1~MI8 status	Read only			0	0	0	0	0	0
00-51	Car-top board input terminal RY1~RY8 status	Read only			0	0	0	0	0	0
00-52	Number of operations (in ten thousands)	Read only	_3		0	0	0	0	0	0
00-53	Number of operations (times)	Read only			0	0	0	0	0	0
00-54	External display board communication status 1 (Floor 1 ~ 16)	Read only			0	0	0	0	0	0
00-55	External display board communication status 2 (Floor 17 ~ 32)	Read only			0	0	0	0	0	0
	External display board	Read only			+	+	1		1	1

	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	
	communication status 3 (Floor 33 ~ 48)			A 6				Ī
00-57	PGHS card error code	Read only			-	0	0	1
00-58	Direction + the most distant floor	Read only			0	0	0	
00-59	Target floor	Read only			0	0	0	
00-60	First error record	Read only			0	0	0	
00-61	First error time (minute)	Read only			0	0	0	
00-62	First error time (days)	Read only	4		0	0	0	
00-63	Display the speed command on error	Read only			0	0	0	
00-64	Display the output voltage on error	Read only	4		0	0	0	
00-65	Display the VBUS voltage on error	Read only			0	0	0	
00-66	Display output speed on error	Read only			0	0	0	
00-67	Display the output current on error	Read only			0	0	0	
00-68	Display the motor speed on error	Read only			0	0	0	
00-69	Display the output power on error	Read only			0	0	0	
00-70	Display output torque on error	Read only			0	0	0	
00-71	Display the multi-function input terminal MI1~MI8 status on error	Read only			0	0	0	
00-72	Display the multi-function input terminal MI9~MI22 status on error	Read only			0	0	0	
00-73	Reserved	-0^						
00-74	Display the multi-function terminal RY1 ~ RY16 status on	Read only	100		0	0	0	
00-75	Display the driving status of IED operation fault	Read only			0	0	0	
00-76	Second error record	Read only				0	0	
00-77	Second error time (minute)	Read only			0	0	0	
00-78	Second error time (days)	Read only			0	0	0	
00-79	Third error record	Read only			0	0	0	
00-80	Third error time (minute)	Read only			0	0	0	
00-81	Third error time (days)	Read only			0	0	0	
00-82	Fourth error record	Read only		20	0	0	0	
00-83	Fourth error time (minute)	Read only			0	0	0	
00-84	Fourth error time (days)	Read only			0	0	0	
00-85	Fifth error record	Read only			0	0	0	
00-86	Fifth error time (minute)	Read only			0	0	0	
00-87	Fifth error time (days)	Read only			0	0	0	
00-88	Sixth error record	Read only			0	0	0	
00-89	Sixth error time (minute)	Read only			0	0	0	
00-90	Sixth error time (days)	Read only			0	0	0	
00-91	Data display	Read only			0	0	0	
00-92	Display motor continuous running time (minutes)	Read only			0	0	0	
00-93	Display motor continuous running time (days)	Read only			0	0	0	
7	Rated current	Read only			0	0	0	
00-94 00-95	Firmware version	Read only			0	0	0	

01 System Parameters

★ The parameter can be set during operation

Parameter code	Function of the parameter	Parameter range	level	Default value	٧F	VFPG	SVC	FOCPG	TQCPG	FOCPM
01-00	Identity code of IED	8: 230V, 3HP 10: 230V, 5HP 11: 460 V, 5HP (4.0kW) 12: 230V, 7.5HP 13: 460 V, 7.5HP 14: 230V, 10HP		Read only	0	0	0	0	0	0
	In Harry	15: 460V, 10HP 16: 230V, 15HP 17: 460V, 15HP 18: 230V, 20HP 19: 460V, 20HP 20: 230V, 25HP								
N	MAN IID.	21: 460V, 25HP 22: 230V, 30HP 23: 460V, 30HP 24: 230V, 40HP 25: 460V, 40HP 26: 230V, 50HP						•		-
01-01	Desembles management	27: 460V, 50HP 29: 460V, 60HP 31: 460V, 75HP 33: 460V, 100HP		0						
01-01	Parameter management setting	 0: No function 1: Parameter write proof 3: Show the hidden parameter(☑) 8: Panel operation is disabled 9: Parameter reset (Base frequency is 50Hz) 10: Parameter reset (Base frequency is 60Hz) 			0	0	0	0	0	0
01-02	Control method	0: V/F control 1: V/F control + Encoder (VFPG) 2: Sensorless vector control (SVC) 3: FOC vector control + Encoder (FOCPG) 4: Torque control + Encoder (TQCPG) 8: FOC PM control (FOCPM)		0	0	0	0	0	0	0
01-03	System control	bit 0=0: No function bit 0=1: ASR automatic adjustment, PDFF enable bit 7=0: No function bit 7=1: Startup position control is enabled bit 10=0: No function bit 10 = 1: Direct parking is enabled		0x0481h				0		0
	i. The	bit 15=0: No function bit 15=1: Magnetic pole detection is disabled when power on								
01-04	Elevator speed	0.10 ~ 4.00 m/s		1.00				0		0
01-05	Maximum Operation Frequency	10.00 ~ 400.00Hz	\$	60.00/ 50.00	0	0	0	0	0	0
01-06	Parameter protection unlock password input	1~9998 · 10000~65535 0~2: Record the times of error passwords input		0	0	0	0	0	0	0
01-07	Parameter protection password setting	1~9998 · 10000~65535 0: Password is not set or input correct password (01-06)	☑	0	0	0	0	0	0	0

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
		1: Parameters have been locked								
01-08	Carrier Frequency	2 ~ 15KHz	Ø	12	0	0	0	0	0	0
01-09	Automatic Voltage Rectifying (AVR) function	0: Enable AVR 1: Disable AVR 2: Disable AVR during parking deceleration	Ø	0	0	0	0	0	0	0
01-10	Fan control	0: Fan always ON 1: 1 minute after AC motor drive stops, fan will be OFF 2: AC motor drive runs and fan ON, AC motor drive stops and fan OFF 3: Fan ON to run when preliminary heat sink temperature attained 4: Fan always OFF		2	0	0	0	0	0	0
01-11	Elevator acceleration	$0.20 \sim 2.00 \text{m/s}^2$	\square	0.75	0	0	0	0	0	С
01-12	Motor current at Accel.	50~200%	\square	150	0	0	0	0	0	0
01-13	Monitoring data address	0~FFFF	\square	0	0	0	0	0	0	0
1	Real time clock (RTM_HOURMIN)	00~2359	Ø	0	0	0	0	0	0	0
	Real time clock (RTM_WEEK)	0~6	Ø	0	0	0	0	0	0	0
	Real time clock (RTM_MONDAY)	101~1231	Ø	101	0	0	0	0	0	0
	Real time clock (RTM_YEAR)	0~99	\square	0	0	0	0	0	0	0

02 Motor Parameters

★ : The parameter can be set during operation

Paramete code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
02-00	Motor Auto Tuning	0: No function 1: Rolling test 2: Static test		0			0	0	0	0
02-01	Full-load Current of Motor	(30 ~ 120%) * the model's rated current (Amps)		#.##	0	0	0	0	0	0
02-02	Rated power of Motor	0.00 ~ 655.35kW		#.##			0	0	0	0
02-03	Rated speed of Motor (rpm)	0~65535		1710		0	0	0	0	0
02-04	Number of Motor Poles	2~96		4	0	0	0	0	0	0
02-05	Angle between Magnetic Pole and PG Origin	0.0~360.0°		360.0						0
02-06	Output Direction Selection	Same as the configured direction Opposite to the configured direction		0	0	0	0	0	0	0
02-07	Encoder type selection	0: No function 1: ABZ 2: ABZ + Hall 3: SIN/COS + Sinusoidal 4: SIN/COS + Endat 5: SIN/COS 6: SIN/COS + Hiperface	110	0		0		0	0	0
02-08	Encoder Pulse	1~25000		600		0		0	0	0
02-09	Encoder's input type setting	O: No function 1: Phases A/B are pulse inputs: Phase A is 90 degree leading Phase B with forward rotation 2: Phases A/B are pulse inputs: Phase B is 90 degree leading Phase A		0		0		0	0	0
	MAN TO THE PARTY OF THE PARTY O	with forward rotation 3: Phase A is a pulse input; Phase B is the direction input: L is reverse direction and H is forward direction 4: Phase A is a pulse input; Phase B is the direction input: L is forward direction and H is reverse direction 5: Single phase input			S					
02-10	U, V, W input mode selection	0: Z signal is at the falling edge of Phase U 1: Z signal is at the leading edge of Phase U		0		0		0	0	0
02-11	Rated frequency of Motor	0.00 ~ 400.00Hz		60.00/ 50.00	0	0	0	0	0	0
02-12	Rated voltage of Motor	230V Series: 0.0V ~ 255.0V 460V Series: 0.0V ~ 510.0V		220.0 440.0	0	0	0	0	0	0
02-13	No-load current of Motor	0 ~ Motor's full load current (Parameter 02-01) setting	☑	#.##	3	0	0	0	0	
02-14	Stator Resistance (Rs) of Motor	0.000~65.535Ω	Ø	0.000			0	0	0	
	_									

code	Function of the parameter	Parameter range	level	Default value	\ \ \	VFPG	SVC	FOCPG	TQCPG	FOCPM
02-15	of Motor	0.000~65.535Ω	Ø	0.000			0	0	0	
02-16	Magnetizing Inductance (Lm) of Motor	0.0~6553.5mH	Ø	0.0			0	0	0	
02-17		0.0~6553.5mH	Ø	0.0			0	0	0	
02-18	Back Electromotive Force	0.0~6553.5Vrms	Ø	0.0						0
02-19	Magnetic Pole Re-positioning	Reserved Reconfigure the magnetic positioning Reserved	Ø	0						0
02-20	Torque Compensation Time Constant	0.001 ~ 10.000 seconds	Ø	0.020			0			
02-21	Slip Compensation Time Constant	0.001 ~ 10.000 seconds	Ø	0.100			0			
02-22	Torque Compensation Gain	0~10	Ø	0	0	0				
02-23		0.00~10.00	Ø	0.00	0	0	0			
02-24	Slip Deviation Level	0~1000% (0: not detecting)	Ø	0		0	0	0		
02-25	Detection Time of Slip Deviation	0.0 ~ 10.0 seconds	Ø	1.0		0	0	0		
02-26	Over Slip Treatment	Warn and keep operation Warn and ramp to stop Warn and coast to stop	Ø	0		0	0	0		
02-27	Hunting Gain	0~10000 (0: not activated)	$\overline{\mathbf{Q}}$	2000	0	0	0			
02-28	Accumulative Motor Operation Time (Min.)	00~1439	<u> </u>	00	0	0	0	0	0	0
02-29	Accumulative Drive Power on Time (day)	00~65535	Ø	00	0	0	0	0	0	0
02-30	2 nd Output Frequency Setting 1	0.00 ~ 400.00Hz	Ø	0.50	0	0				
02-31	2 nd Output Voltage Setting 1	230V Series: 0.0V ~ 255.0V 460V Series: 0.0V ~ 510.0V	Ø	5.0 10.0	0	0			3	
02-32	3 rd Output Frequency Setting 1 3 rd Output Voltage	0.00 ~ 400.00Hz		0.50	0	0				
02-33	3 rd Output Voltage Setting 1 4 th Output Frequency	230V Series: 0.0V ~ 255.0V 460V Series: 0.0V ~ 510.0V 0.00 ~ 400.00Hz	Ø	5.0 10.0 0.00	0	0	0		0	
02-35	Setting 1 4 th Output Voltage	230V Series: 0.0V ~ 255.0V	Ø	0.00	0	0		0		
02 00	Setting 1	460V Series: 0.0V ~ 510.0V	Ø	0.0					0	
	Start Frequency	0.00 ~ 400.00Hz	_	0.00	+	0	0	0	1	

03 Multi-function Output/Input Function Parameters

★ The parameter can be set during operation

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
03-00	Multi-function input command 1 (MI1)	0: No function (Normal Open)		101	0	0	0	0	0	0
03-01	Multi-function input command 2 (MI2)	1: Inspection signal (Normal Open)		2	0	0	0	0	0	0
03-02	Multi-function input command 3 (MI3)	2: Inspection up-going (Normal Open)		3					0	
03-03	Multi-function input command 4 (MI4)	3: Inspection down-going (Normal Open)		4	0	0	0	0	0	0
03-04	Multi-function input command 5 (MI5)	4: Upper leveling signal (Normal Open)		5	0	0	0	0	0	0
03-05	Multi-function input command 6 (MI6)	5: Lower leveling signal (Normal Open)		6	0	0	0	0	0	0
03-06	Multi-function input command 7 (MI7)	6: Door position input (Normal Open)		7	0	0	0	0	0	0
03-07	Multi-function input command 8 (MI8)	7: Door inter-lock circuit feedback (Normal Open)		8	0	0	0	0	0	0
03-08	Multi-function input command 9 (MI9)	8: Brake circuit feedback (Normal Open)		9	0	0	0	0	0	0
03-09	Multi-function input command 10 (MI10)	9: Operation output feedback (Normal Open)	-	101	0	0	0	0	0	0
03-10	Multi-function input command 11 (MI11)	10: Safety circuit feedback (Normal Open)	3	111	0	0	0	0	0	0
03-11	Multi-function input command 12 (MI12)	11: Up-most limit signal (Normal Open)		112	0	0	0	0	0	0
03-12	Multi-function input command 13 (MI13)	12: Upward 1 st level forced deceleration (Normal Open)	-	113	0	0	0	0	0	0
03-13	Multi-function input command 14 (MI14)	13: Upward 2 nd level forced deceleration (Normal Open)		114	0	0	0	0	0	0
03-14	Multi-function input command 15 (MI15)	14: Upward 3 rd level forced deceleration (Normal Open)	0	115	0	0	0	0	0	0
03-15	Multi-function input command 16 (MI16)	15: Down-most limit signal (Normal Open)		116	0	0	0	0	0	0
03-16	Multi-function input command 17 (MI17)	16: Downward 1 st level forced deceleration (Normal Open)		117	0	0	0	0	0	0
03-17	Multi-function input command 18 (MI18)	17: Downward 2 nd level forced deceleration (Normal Open)	-	118	0	0	0	0	0	0
03-18	Multi-function input command 19 (MI19)	18: Downward 3rd level forced deceleration (Normal Open)		0	0	0	0	0	0	0
03-19	Multi-function input command 20 (MI20)	19: Door pre-opening output feedback (Normal Open)		0	0	0	0	0	0	0
03-20	Multi-function input command 21 (MI21)	20: Safety circuit feedback 2 (Normal Open)	-	0	0	0	0	0	0	0
03-21	Multi-function input command 22 (MI22)	21: Brake close feedback 2 (Normal Open)		0	0	0	0	0	0	0
03-22	Multi-function input command 23 (MI23)	22: Door close circuit feedback 2 (Normal Open)		0	0	0	0	0	0	0
03-23	Multi-function input command 24 (MI24)	23: Overload input (Normal Open)	3	0	0	0	0	0	0	0
03-24	Extension Multi-function input command 1 (XI1)	24: Full-load input (Normal Open)	-	0	0	0	0	0	0	0

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	
03-25	Extension Multi-function input command 2 (XI2)	25: Fire signal (Normal Open)		0	0	0	0	0	0	0	
03-26	Extension Multi-function input command 3 (XI3)	26: Fire mode (Normal Open)		0	0	0	0	0	0	0	
03-27	Extension Multi-function input command 4 (XI4)	27: Light curtain signal 1 (Normal Open)		0	0	0	0	0	0	0	
03-28	Extension Multi-function input command 5 (XI5)	28: Light curtain signal 2 (Normal Open)		0	0	0	0	0	0	0	
03-29	Extension Multi-function input command 6 (XI6)	29: Elevator lock signal (Normal Open)		0	0	0	0	0	0	0	
03-30	Extension Multi-function input command 7 (XI7)	30: Emergency power supply feedback (Normal Open)		0	0	0	0	0	0	0	
03-31	Extension Multi-function input command 8 (XI8)	101: Inspection signal (Normal Close)		0	0	0	0	0	0	0	
03-32	Extension Multi-function input command 9 (XI9)	102: Inspection up-going (Normal Close)		0	0	0	0	0	0	0	
03-33	Extension Multi-function input command 10 (XI10) Extension Multi-function input command 11 (XI11) Extension Multi-function input command 12	103: Inspection down-going (Normal Close)		0	0	0	0	0	0	0	
03-34		104: Upper leveling signal (Normal Close)		0	0	0	0	0	0	0	
03-35	Extension Multi-function input command 12	105: Lower leveling signal (Normal Close)		0	0	0	0	0	0	0	
	(XI12)	106: Door position input (Normal Close) 107: Door inter-lock circuit feedback (Normal Close)									
	The state of	108: Brake circuit feedback (Normal Close) 109: Operation output feedback (Normal Close)									
	1 1 1 1 (() 1 1 (() 1 (() 1 (() 1 () 1	110: Safety circuit feedback (Normal Close) 111: Up-most limit signal (Normal Close) 112: Upward 1 st level forced deceleration	- 5								
		(Normal Close) 113: Upward 2 nd level forced deceleration (Normal Close)		3							
		114: Upward 3 rd level forced deceleration (Normal Close)									
		115: Down-most limit signal (Normal Close) 116: Downward 1 st level forced deceleration (Normal Close) 117: Downward 2 nd level forced deceleration (Normal Close)				C					
		118: Downward 3rd level forced deceleration (Normal Close) 119: Door pre-opening output feedback (Normal		30						>	
		Close) 120: Safety circuit feedback 2 (Normal Close) 121: Brake close feedback 2 (Normal Close) 122: Door close circuit feedback 2 (Normal Close)									
		123: Overload input (Normal Close) 124: Full-load input (Normal Close) 125: Fire signal (Normal Close)		1							
		126: Fire mode (Normal Close) 127: Light curtain signal 1 (Normal Close) 128: Light curtain signal 2 (Normal Close)		~							
		129: Elevator lock signal (Normal Close)									

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
		130: Emergency power supply feedback (Normal Close)		.43						
03-36	Digital input direction 1	0~65535		0	0	0	0	0	0	C
03-37	Digital input direction 2	0~65535		0	0	0	0	0	0	
03-38	Digital input direction 3	0~65535		0	0	0	0	0	0	
03-39	Digital input response time			0.005	0	0	0	0	0	ļ.
03-40	Multi-function output Relay 1 (RA)	0: No function		1	0	0	0	0	0	
03-41	, ,	1: Motor's solenoid valve control output		2	0	0	0	0	0	(
03-42	3 (R1A)	2: Mechanical brake release		3	0	0	0	0	0	C
03-43	4 (R2A)	3: Mechanical brake enhanced release		0	0	0	0	0	0	
03-44	5 (R3A)	4: Mechanical brake, electromagnetic contactor normal		0	0	0	0	0	0	(
03-45	Multi-function output Relay 6 (R4A)			0	0	0	0	0	0	(
03-46	Multi-function output Relay 7 (R5A)			0	0	0	0	0	0	
03-47	Multi-function output Relay 8 (R6A)	7: Group control ready		0	0	0	0	0	0	(
03-48	Multi-function output Relay 9	8: Door pre-opening contactor output		0	0	0	0	0	0	(
03-49	Multi-function output Relay 10	9: Door motor 1 open		0	0	0	0	0	0	(
03-50	Multi-function output Relay 11	10: Door motor 1 close		0	0	0	0	0	0	(
03-51	Multi-function output Relay 12	11: Door motor 2 open		0	0	0	0	0	0	(
03-52	Multi-function output Relay 13	12: Door motor 2 close		0	0	0	0	0	0	(
03-53	Multi-function output Relay 14	13: Door inter-lock circuit output		0	0	0	0	0	0	
03-54	Multi-function output Relay 15	14: Emergency power output		0	0	0	0	0	0	(
03-55	Multi-function output Relay 16	15: PM motor three-phase short circuit output		0	0	0	0	0	0	(
03-56	-	0~65535		0	0	0	0	0	0	(
03-57	AUI1 analog input function selection	0: No function1: Preload input2: PTC thermistor input3~10: reserved		1	0	0	0	0	0	
03-58	AUI1 analog input bias	-100.0~100.0%	R	0.0	0	0	0	0	0	(
03-59	AUI1 analog input gain	-500.0~500.0%		100.0	0	0	0	0	0	(
03-60	Torque Offset Selection (TOROFSE)	0: No weighting signal 1: Signal from Analog input 2: Signal from Car-top board input 3: Reserved		0			0	0	0	C

Floor Position Parameters

Parameter Code Parameter Parameter range											
04-01 Distance between upper and lower leveling signals 04-02 Floor 1 position - high 0 - 999.9mm 0.0 0 0 0 0 0 0 0 0			Parameter range	level		VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
04-01 Distance between upper and lower leveling signals 04-02 Floor 1 position - high 0 - 9999m 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	04-00	Landing board length	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-03		Distance between upper and lower leveling				0	0	0	0		0
Q4-04 Floor 2 position - high 0 - 9999m 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	04-02	Floor 1 position - high	0 ~ 9999m		0	0	0	0	0		0
04-05 Floor 2 position - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0	04-03	Floor 1 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-06 Floor 3 position - high 0 ~ 9999m 0	04-04	Floor 2 position - high	0 ~ 9999m		0	0	0	0	0		0
04-07 Floor 3 position - low 0.0 ~ 999.9mm	04-05	Floor 2 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0	k .	0
04-08 Floor 4 position - high 0 ~ 9999m 0.0 0 ~ 0 0	04-06	Floor 3 position - high	0 ~ 9999m		0	0	0	0	0		0
04-08 Floor 4 position - high 0 ~ 9999m 0.0 0 ~ 0 0	04-07	Floor 3 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-09 Floor 4 position - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0						0	0	0	0		0
04-10 Floor 5 position - high 0 ~ 9999m 0.0 0 ~ 0 0					0.0	0	0	0	0		0
04-11 Floor 5 position - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0						0	0	0	0		0
04-12 Floor 6 position - high 0 ~ 999.9mm 0.0 0								0	0		0
04-13 Floor 6 position - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0								<u> </u>			0
04-14 Floor 7 position - high 0 ~ 9999m 0											0
04-15 Floor 7 position - low 0.0 ~ 999.9mm 0.0 0 <											0
04-16 Floor 8 position - high 0 ~ 9999m 0 0 ~ 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		<u> </u>			-			<u> </u>			0
04-17 Floor 8 position - low 0.0 ~ 999.9mm 0.0 0 0 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td><u> </u></td> <td></td> <td></td> <td>0</td>								<u> </u>			0
04-18 Floor 9 position - high 0 ~ 9999m 0					-						0
04-19 Floor 9 position - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0						_					0
04-20 Floor 10 position - high 0 ~ 9999m 0				. 1				_			
04-21 Floor 10 position - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0											0
04-22 Floor 11 position - high 0 ~ 9999mm 0.0 0 0 0<								~			0
04-23 Floor 11 position - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0											0
04-24 Floor 12 position - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 .					-						0
04-25 Floor 12 position - low 0.0 ~ 999.9mm 0.0 0		· · · · · · · · · · · · · · · · · · ·						_			0
04-26 Floor 13 position - high 0 ~ 9999m 0					-	_					0
04-27 Floor 13 position - low 0.0 ~ 999.9mm 0.0 ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° °						0	0	0	- 1		0
04-28 Floor 14 position - high 0 ~ 9999m 0		-			-	0	0	0	0		0
04-29 Floor 14 position - low 0.0 ~ 9999.9mm 0.0 ° ° ° ° ° 04-30 Floor 15 position - high 0 ~ 9999m 0 ° ° ° ° 04-31 Floor 15 position - low 0.0 ~ 999.9mm 0.0 ° ° ° 04-32 Floor 16 position - high 0 ~ 9999m 0 ° ° ° 04-33 Floor 16 position - low 0.0 ~ 999.9mm 0.0 ° ° ° 04-34 Floor 17 position - high 0 ~ 9999m 0 ° ° ° 04-35 Floor 17 position - low 0.0 ~ 999.9mm 0.0 ° ° ° 04-36 Floor 18 position - high 0 ~ 9999m 0 ° ° ° 04-37 Floor 18 position - low 0.0 ~ 999.9mm 0.0 ° ° ° 04-38 Floor 19 position - high 0 ~ 999.9mm 0 ° ° ° 04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 ° ° ° 04-40 Floor 20 position - high 0 ~ 999.9mm 0 ° ° ° 04-41 Floor 21 position - low 0.0 ~ 999.9mm 0 ° ° ° 04-42 Floor 21 position - low 0.0 ~ 999.9mm 0 ° ° ° 04-43 Floor 21 position - low 0.0 ~ 99						0	0	0	0		0
04-30 Floor 15 position - high 0 ~ 9999m 0 <td></td> <td></td> <td></td> <td></td> <td>-</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td></td> <td>0</td>					-	0	0	0	0		0
04-31 Floor 15 position - low 0.0 ~ 999.9mm 0.0 0 0 04-32 Floor 16 position - high 0 ~ 999.9mm 0.0 0 0 04-33 Floor 16 position - low 0.0 ~ 999.9mm 0.0 0 0 04-34 Floor 17 position - high 0 ~ 999.9mm 0 0 0 04-35 Floor 17 position - low 0.0 ~ 999.9mm 0.0 0 0 04-36 Floor 18 position - high 0 ~ 999.9mm 0 0 0 04-37 Floor 18 position - low 0.0 ~ 999.9mm 0.0 0 0 04-38 Floor 19 position - high 0 ~ 999.9mm 0 0 0 04-39 Floor 19 position - low 0.0 ~ 999.9mm 0 0 0 04-40 Floor 20 position - high 0 ~ 999.9mm 0 0 0 04-41 Floor 20 position - high 0 ~ 999.9mm 0 0 0 04-42 Floor 21 position - high 0 ~ 999.9mm 0 0 0 0 04-43 Floor 22 position - high 0 ~ 999.9mm <td< td=""><td></td><td></td><td></td><td></td><td>0.0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td><td>0</td></td<>					0.0	0	0	0	0		0
04-32 Floor 16 position - high 0 ~ 9999m 0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0				,		0	0	0	0		0
04-33 Floor 16 position - low 0.0 ~ 999.9mm 0.0 0 0 04-34 Floor 17 position - high 0 ~ 999.9mm 0 0 0 04-35 Floor 17 position - low 0.0 ~ 999.9mm 0.0 0 0 04-36 Floor 18 position - high 0 ~ 999.9mm 0 0 0 04-37 Floor 18 position - low 0.0 ~ 999.9mm 0.0 0 0 04-38 Floor 19 position - high 0 ~ 999.9mm 0 0 0 04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 0 0 04-40 Floor 20 position - high 0 ~ 999.9mm 0 0 0 04-41 Floor 20 position - low 0.0 ~ 999.9mm 0 0 0 04-42 Floor 21 position - high 0 ~ 999.9mm 0 0 0 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0 0 0 0 04-44 Floor 22 position - high 0 ~ 999.9mm 0 0	04-31	Floor 15 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-34 Floor 17 position - high 0 ~ 9999m 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	04-32	Floor 16 position - high	0 ~ 9999m		0	0	0	0	0		0
04-35 Floor 17 position - low 0.0 ~ 999.9mm 0.0 0 0 04-36 Floor 18 position - high 0 ~ 9999m 0 0 0 04-37 Floor 18 position - low 0.0 ~ 999.9mm 0.0 0 0 04-38 Floor 19 position - high 0 ~ 999.9mm 0 0 0 04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 0 0 04-40 Floor 20 position - high 0 ~ 999.9mm 0 0 0 04-41 Floor 20 position - low 0.0 ~ 999.9mm 0 0 0 04-42 Floor 21 position - high 0 ~ 999.9mm 0 0 0 04-43 Floor 22 position - high 0 ~ 999.9mm 0 0 0 04-44 Floor 22 position - high 0 ~ 999.9mm 0 0 0	04-33	Floor 16 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-36 Floor 18 position - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 04-37 Floor 18 position - low 0.0 ~ 999.9mm 0.0 . 0 . 0 . 0 04-38 Floor 19 position - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 . 0 . 0 . 0 . 0 04-40 Floor 20 position - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 . 0 04-41 Floor 20 position - low 0.0 ~ 999.9mm 0.0 . 0 . 0 . 0 . 0 . 0 04-42 Floor 21 position - high 0 ~ 999.9mm 0 . 0 . 0 . 0 . 0 . 0 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 . 0 . 0 . 0 . 0 04-44 Floor 22 position - high 0 ~ 999.9mm 0 . 0 . 0 . 0 . 0	04-34	Floor 17 position - high	0 ~ 9999m		0	0	0	0	0		0
04-37 Floor 18 position - low 0.0 ~ 999.9mm 0.0 ° ° ° ° ° 04-38 Floor 19 position - high 0 ~ 9999m 0 ° ° ° ° 04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 ° ° ° ° 04-40 Floor 20 position - high 0 ~ 9999m 0 ° ° ° ° 04-41 Floor 20 position - low 0.0 ~ 999.9mm 0.0 ° ° ° ° 04-42 Floor 21 position - high 0 ~ 999.9mm 0 ° ° ° ° 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 ° ° ° 04-44 Floor 22 position - high 0 ~ 999.9mm 0 ° ° ° 04-44 Floor 22 position - high 0 ~ 999.9mm 0 ° ° °	04-35	Floor 17 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-38 Floor 19 position - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 . 0 . 0 . 0 04-40 Floor 20 position - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 04-41 Floor 20 position - low 0.0 ~ 999.9mm 0.0 . 0 . 0 . 0 . 0 04-42 Floor 21 position - high 0 ~ 999.9mm 0 . 0 . 0 . 0 . 0 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 . 0 . 0 . 0 04-44 Floor 22 position - high 0 ~ 9999m 0 . 0 . 0 . 0	04-36	Floor 18 position - high	0 ~ 9999m		0	0	0	0	0		0
04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-40 Floor 20 position - high 0 ~ 9999m 0 0 0 0 04-41 Floor 20 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-42 Floor 21 position - high 0 ~ 999.9mm 0 0 0 0 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-44 Floor 22 position - high 0 ~ 9999m 0 0 0 0	04-37	Floor 18 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-39 Floor 19 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-40 Floor 20 position - high 0 ~ 9999m 0 0 0 0 04-41 Floor 20 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-42 Floor 21 position - high 0 ~ 999.9mm 0 0 0 0 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-44 Floor 22 position - high 0 ~ 9999m 0 0 0 0	04-38	Floor 19 position - high	0 ~ 9999m		0	0	0	0	0		0
04-41 Floor 20 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-42 Floor 21 position - high 0 ~ 9999m 0 0 0 0 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-44 Floor 22 position - high 0 ~ 9999m 0 0 0 0	04-39	Floor 19 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-41 Floor 20 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-42 Floor 21 position - high 0 ~ 9999m 0 0 0 0 04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-44 Floor 22 position - high 0 ~ 9999m 0 0 0 0	04-40	Floor 20 position - high				0	0	0	0	(0	0
04-42 Floor 21 position - high 0 ~ 9999m 0 <td></td> <td></td> <td></td> <td></td> <td>0.0</td> <td>0</td> <td>0</td> <td>0,</td> <td>0</td> <td></td> <td>0</td>					0.0	0	0	0,	0		0
04-43 Floor 21 position - low 0.0 ~ 999.9mm 0.0 0 0 0 04-44 Floor 22 position - high 0 ~ 9999m 0 0 0 0						0	0	0	0		0
04-44 Floor 22 position - high 0 ~ 9999m 0 0 0 0 0						_	- 60				0
						-		H	0		0
- - - - - - - -									0		0
04-46 Floor 23 position - high 0 ~ 9999m 0 0 0 0 0											0
04-47 Floor 23 position - low 0.0 ~ 999.9mm 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0											0

					1	1	1	1		
Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
04-48	Floor 24 position - high	0 ~ 9999m		0	0	0	0	0		0
04-49	Floor 24 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-50	Floor 25 position - high	0 ~ 9999m		0	0	0	0	0		0
04-51	Floor 25 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-52	Floor 26 position - high	0 ~ 9999m		0	0	0	0	0		0
04-53	Floor 26 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-54	Floor 27 position - high	0 ~ 9999m		0	0	0	0	0		0
04-55	Floor 27 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-56	Floor 28 position - high	0 ~ 9999m		0.0	0	0	0	0	\vdash	0
04-57	Floor 28 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-58	Floor 29 position - high	0 ~ 9999m		0.0	0	0	0	0		0
04-58	Floor 29 position - low	0.0 ~ 999.9mm		0.0	+			-		
	· · · · · · · · · · · · · · · · · · ·				0	0	0	0		0
04-60	Floor 30 position - high	0 ~ 9999m		0	0	0	0	0		0
04-61	Floor 30 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0	H	0
04-62	Floor 31 position - high	0 ~ 9999m		0	0	0	0	0		0
04-63	Floor 31 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-64	Floor 32 position - high	0 ~ 9999m		0	0	0	0	0		0
04-65	Floor 32 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-66	Floor 33 position - high	0 ~ 9999m		0	0	0	0	0		0
04-67	Floor 33 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-68	Floor 34 position - high	0 ~ 9999m		0	0	0	0	0		0
04-69	Floor 34 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-70	Floor 35 position - high	0 ~ 9999m		0	0	0	0	0		0
04-71	Floor 35 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-72	Floor 36 position - high	0 ~ 9999m		0	0	0	0	0		0
04-73	Floor 36 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-74	Floor 37 position - high	0 ~ 9999m		0	0	0	0	0		0
04-75	Floor 37 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-76	Floor 38 position - high	0 ~ 9999m		0	0	0	0	0		0
04-77	Floor 38 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-78	Floor 39 position - high	0 ~ 9999m		0	0	0	0	0		0
04-79	Floor 39 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-80	Floor 40 position - high	0 ~ 9999m		0	0	0	0	0	. 1	0
04-81	Floor 40 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-82	Floor 41 position - high	0 ~ 9999m		0.0	0	0	0	0		0
04-83	Floor 41 position - low	0.0 ~ 999.9mm		0.0			0	0		0
		0 ~ 9999m			0	0				
04-84	Floor 42 position - high			0	0	0	0	0	H	0
04-85	Floor 42 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-86	Floor 43 position - high	0 ~ 9999m		0	0	0	0	0		0
04-87	Floor 43 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-88	Floor 44 position - high	0 ~ 9999m		0	0	0	0	0		0
04-89	Floor 44 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-90	Floor 45 position - high	0 ~ 9999m		0	0	0	0	0		0
04-91	Floor 45 position - low	0.0 ~ 999.9mm	72	0.0	0	0	0	0	<u> </u>	0
04-92	Floor 46 position - high	0 ~ 9999m		0	0	0	0	0	<u> </u>	0
04-93	Floor 46 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
04-94	Floor 47 position - high	0 ~ 9999m		0	0	0	0	0		0
04-95	Floor 47 position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0

05 Parameters for Floor Display

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
05-00	Physical floor 1 indication	0~9999		1	0	0	0	0		0
05-01	Physical floor 2 indication			2	0	0	0	0		0
05-02	Physical floor 3 indication	Settings: XX YY		3	0	0	0	0		0
05-03	Physical floor 4 indication	XX: Tens digit		4	0	0	0	0		0
05-04	Physical floor 5 indication	YY: Units digit		5	0	0	0	0		0
05-05	Physical floor 6 indication			6	0	0	0	0		0
05-06	Physical floor 7 indication	00='0'		7	0	0	0	0		0
05-07	Physical floor 8 indication	01='1'		8	0	0	0	0		0
05-08	Physical floor 9 indication	02='2'		9	0	0	0	0		0
05-09	Physical floor 10 indication	03='3'		100	0	0	0	0		0
05-10	Physical floor 11 indication			101	0	0	0	0		0
05-11	Physical floor 12 indication			102	0	0	0	0		0
05-12	Physical floor 13 indication	06='6'		103	0	0	0	0		0
05-13	Physical floor 14 indication			104	0	0	0	0		0
05-14	Physical floor 15 indication		X O	105	0	0	0	0		0
05-15	Physical floor 16 indication			106	0	0	0	0		0
05-16	Physical floor 17 indication			107	0	0	0	0		0
05-17	Physical floor 18 indication			108	0	0	0	0		0
05-18	Physical floor 19 indication			109	0	0	0	0		0
05-19	Physical floor 20 indication			200	0	0	0	0		0
05-20	Physical floor 21 indication			201	0	0	0	0		0
05-21	Physical floor 22 indication			202	0	0	0	0		0
05-22	Physical floor 23 indication			203	0	0	0	0		0
05-23	Physical floor 24 indication			204	0	0	0	0		0
05-24	Physical floor 25 indication			205	0	0	0	0		0
05-25	Physical floor 26 indication			206	0	0	0	0	\vdash	0
05-26	Physical floor 27 indication			207	0	0	0	0	\vdash	0
05-27	Physical floor 28 indication			208	0	0	0	0		0
05-28	Physical floor 29 indication			209	0	0	0	0		0
05-29	Physical floor 30 indication			300	0	0	0	0		0
05-30	Physical floor 31 indication			301	0	0	0	0	\vdash	0
05-31	Physical floor 32 indication			302	0	0	0	0	\vdash	0
05-32	Physical floor 33 indication			303	0	0	0	0		0
05-33	Physical floor 34 indication			304	0	0	0	0		0
05-34	Physical floor 35 indication			305	0	0	0	0		0
05-35	Physical floor 36 indication			306	0	0	0	0		0
05-36	Physical floor 37 indication			307	0	0	0	0		0
05-37	Physical floor 38 indication			308	0	0	0	0	\vdash	0
05-38	Physical floor 39 indication			309	0	0	0	0	\vdash	0
05-39	Physical floor 40 indication			400	0	0	0	0	\vdash	0
05-40	Physical floor 41 indication			401	0	0	0	0	\vdash	0
05-41	Physical floor 42 indication			402	0	0	0	0		0
05-42	Physical floor 43 indication			403	0	0	0	0		0
05-43	Physical floor 44 indication			404	0	0	0	0		0
05-44	Physical floor 45 indication			405	0	0	0	0	\vdash	0
05-45	Physical floor 46 indication			406	0	0	0	0	\vdash	0
05-46	Physical floor 47 indication			407	0	0	0	0	\vdash	0

06 Parameters for Speed Control

★: The parameter can be set during operation

Parameter code	Function of the parameter	Parameter range	lev el	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
06-00	Acceleration	0.00 ~ 2.00m/s ²		0.50	0	0	0	0		0
06-01	Deceleration	0.00 ~ 2.00m/s ²		0.50	0	0	0	0		0
06-02	Forced deceleration	0.00~2.00 m/s^2		0.75	0	0	0	0		0
06-03	S-curve for Acceleration Departure Time S1	0.00 ~ 25.00 seconds		2.00	0	0	0	0		0
06-04	S-curve for Acceleration Arrival Time S2	0.00 ~ 25.00 seconds		2.00	0	0	0	0		0
06-05	S-curve for Deceleration Departure Time S3	0.30 ~ 4.00 seconds		2.00	0	0	0	0		0
06-06	S-curve for Deceleration Arrival Time S4	0.30 ~ 4.00 seconds		2.00	0	0	0	0		0
06-07	Landing deceleration	0.00~20.00 m/s^2		20.00	0	0	0	0		0
06-08	Reserved speed (zero speed)	0.10 ~ 4.00 m/s		0.00	0	0	0	0		0
06-09	Reserved speed (stepless)	0.10 ~ 4.00 m/s		0.02	0	0	0	0		0
06-10	Floor searching speed	0.10 ~ 4.00 m/s		0.10	0	0	0	0		0
06-11	Inspection speed	0.10 ~ 4.00 m/s		0.10	0	0	0	0		0
06-12	Leveling speed	0.10 ~ 4.00 m/s		0.05	0	0	0	0		0
06-13	Fast operation speed	0.10 ~ 4.00 m/s		1.00	0	0	0	0		0
06-14	Rescue speed	0.10 ~ 4.00 m/s		0.10	0	0	0	0		0
06-15	Brake Release Delay Time when Elevator Starts			0.250	0	0	0	0	0	0
06-16	Brake Engage Delay Time when Elevator Stops	0.000 ~ 65.000 seconds		0.250	0	0	0	0	0	0
06-17	Turn On Delay of Magnetic Contactor between Drive and Motor	0.000 ~ 65.000 seconds		0.200	0	0	0	0	0	0
06-18	and Motor	0.000 ~ 65.000 seconds		0.200	0	0	0	0	0	0
06-19	DC brake current level	0~100%		0	0	0	0			
06-20	DC brake time at startup	0.0 ~ 60.0 seconds		1.0	0	0	0	0		0
06-21	DC brake time at stop	0.0 ~ 60.0 seconds		0.0	0	0	0	0		0
06-22	Time for Decreasing Torque at Stop	0.000 ~ 5.000 seconds		0.000				0	0	0
06-23	Position of lower limit - high	0 ~ 9999m		0	0	0	0	0		0
06-24	Position of lower limit - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
06-25	Downward 1 st level forced deceleration position - high	0 ~ 9999m		0	0	0	0	0		0
06-26	Downward 1 st level forced deceleration position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0
06-27	Downward 2 nd level forced deceleration position - high	0 ~ 9999m		0	0	0	0	0		0
06-28	Downward 2 nd level forced deceleration position - low	0.0 ~ 999.9mm		0.0	0	0	0	0		0

deceleration position - low deceleration Position of upper limit - high	deceleration position - high Normal	deceleration position - high	deceleration position - high	deceleration position										
06-30 Downward 3rd level forced deceleration position - low deceleration position - low high 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	06-30 Downward 3rd level forced deceleration position - low 0.0 - 999.9mm 0.0 - 999.9mm 0.0 - 90 - 90 - 90 1 1 1 1 1 1 1 1 1	Downward 3rd level forced deceleration position - low 0 - 999.9mm 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0	Downward 3rd level forced deceleration position - low 0 - 999.9mm 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0	Downward 3rd level forced deceleration position - low Downward 3rd level forced deceleration - low Downward 3rd level forced Downward 3rd level forced	06-29	deceleration position -	0 ~ 9999m	110	0	0	0	0	0	
06-31 Position of upper limit - high 0 ~ 9999m 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	06-31 Position of upper limit - high 0 - 9999m 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Desition of upper limit - high Desition of upper limit - high Desition of upper limit - high Desition of upper limit - low Desition of upper limit -	Desition of upper limit - high Desition of upper limit - high Desition of upper limit - high Desition of upper limit - low Desition of upper limit -	De-31	06-30	Downward 3rd level forced	0.0 ~ 999.9mm		0.0	0	0	0	0	
06-32 Position of upper limit - low 0.0 ~ 999.9mm 0.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Position of upper limit	Position of upper limit 10w 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	Position of upper limit 10w 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	06-32 Position of upper limit - low 0.0 - 999.9mm 0.0 - 0 0 0 0 0 0 0 0 0	06-31	Position of upper limit -	0 ~ 9999m		0	0	0	0	0	
deceleration position - high	deceleration position - high	deceleration position -	deceleration position -	deceleration position - high	06-32	Position of upper limit -	0.0 ~ 999.9mm	100	0.0	0	0	0	0	
Deceleration position - low Deceleration position - low Deceleration position Deceleration Decelerati	deceleration position - low Upward 2 rd level forced deceleration - high Upward 2 rd level forced deceleration - low Upward 3 rd level forced deceleration - high Upward 3 rd level forced deceleration - high Upward 3 rd level forced deceleration - high Upward 3 rd level forced deceleration - low Upward 3 rd level forced deceleration Upward 3 rd level forced Upward 3 rd level fo	deceleration position - low Upward 2 rd level forced deceleration - high 0.0 ~ 9999m 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	deceleration position - low Upward 2 rd level forced deceleration - high 0.0 ~ 9999m 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	deceleration position - low	06-33	deceleration position -	0 ~ 9999m		0	0	0	0	0	
06-35 Upward 2 nd level forced deceleration - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 .	06-35 Upward 2 nd level forced deceleration - high 0 ~ 9999m 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 .	06-35	06-35	06-35 Upward 2 nd level forced deceleration - high 0 ~ 9999m 0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0	06-34	Upward 1 st level forced	0.0 ~ 999.9mm		0.0	0	0	0	0	
06-36 deceleration - low 0.0 ~ 999.9mm 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0	06-36 deceleration - low deceleration - low 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	06-36 deceleration - low deceleration - low 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	06-36 deceleration - low deceleration - low 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	06-36 deceleration - low deceleration - low 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	06-35	Upward 2 nd level forced	0 ~ 9999m	al Co	0	0	0	0	0	
deceleration - high	deceleration - high 0 ~ 99999m 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	deceleration - high 06-38 Upward 3 rd level forced deceleration - low 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	deceleration - high 06-38 Upward 3 rd level forced deceleration - low 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	deceleration - high 06-38 Upward 3 rd level forced deceleration - low 0.0 ~ 999.9mm 0.0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0 ~ 0	06-36	Upward 2 nd level forced	0.0 ~ 999.9mm		0.0	0	0	0	0	
deceleration - low 06-39 Distance margin for landing deceleration 0.0 ~ 6000.0mm 100.0 ° ° ° ° ° 0.0 ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° °	deceleration - low 06-39 Distance margin for landing deceleration 0.0 ~ 6000.0mm	deceleration - low 06-39 Distance margin for landing deceleration 0.0 ~ 6000.0mm	deceleration - low 06-39 Distance margin for landing deceleration 0.0 ~ 6000.0mm	deceleration - low 0.0 ~ 999.9mm 100.0 o o o o o o o o o o o o o o o o o o	06-37		0 ~ 9999m		0	0	0	0	0	
landing deceleration	landing deceleration	landing deceleration	landing deceleration	landing deceleration	06.30	Upward 3 rd level forced	0.0		0.0	0	0	0	0	
					00-36		0.0 ~ 999.9mm							
						deceleration - low Distance margin for			100.0	0	0	0	0	
					06-39	deceleration - low Distance margin for landing deceleration	0.0 ~ 6000.0mm	V. Allega	is.					
					06-39	deceleration - low Distance margin for landing deceleration	0.0 ~ 6000.0mm		Many of					

07 Parameters for Advanced Speed Control

★: The parameter can be set during operation

Parameter code	Function of the parameter	Parameter range	level	Default value	ΛF	VFPG	SVC	FOCPG	TQCPG	FOCPM
07-00	Inertia Ratio	1~300%		60				0		0
07-01	Zero-speed bandwidth	0 ~ 40Hz		10				0		0
07-02	Low-speed bandwidth	0 ~ 40Hz		10				0		0
07-03	High-speed bandwidth	0 ~ 40Hz		10	R			0		0
07-04	Zero-speed bandwidth at landing	0 ~ 40Hz		10				0		0
07-05	Zero-speed ASR P gain	0.0~500.0%		100.0	0	0	0	0		0
07-06	Zero-speed ASR integration time I	0.000 ~ 10.000 seconds		0.100	0	0	0	0		0
07-07	ASR P1 gain	0.0~500.0%		100.0	0	0	0	0	\Box	-
07-08	ASR integration time I1	0.000 ~ 10.000 seconds		0.100	0	0	0	0	\vdash	0
07-09	ASR P2 gain	0.0~500.0%		100.0	0	0	0	0	\vdash	0
07-09	ASR integration time I2			0.100	_					
		0.000 ~ 10.000 seconds			0	0	0	0		0
07-11	Zero-speed ASR P gain at landing			100.0	0	0	0	0		0
07-12	Zero-speed ASR integration time I at landing	0.000 ~ 10.000 seconds		0.100	0	0	0	0		0
07-13	Low/high speed switching frequency	0.00 ~ 6.67m/s (0: no effect)		0.12	0	0	0	0		0
07-14	ASR Primary Low Pass Filter Gain	0.000 ~ 0.350 seconds		0.008	0	0	0	0		С
07-15	Zero-speed/Low-speed bandwidth adjustment	0.00 ~ 6.67m/s		0.08						0
07-16	Low-speed/High-speed bandwidth adjustment	0.00 ~ 6.67m/s		0.08		0		0		0
07-17	Forward Motor Torque limit	0~300%		200				0	0	0
07-18	Forward Regenerative Torque Limit	0~300%		200			3	0	0	0
07-19	Reverse Motor Torque Limit	0~300%		200				0	0	0
07-20	Reverse Regenerative Torque Limit	0~300%		200				0	0	0
07-21	PDFF gain	0~200%		30				0		0
07-22	Gain for Speed Feed Forward	0~500%		0				0		0
07-23	Operation Time of Zero Speed	0.000 ~ 65.535 seconds		0.450						0
07-24	Zero Speed Gain (P)	0~655.00%		100.00					\Box	0
07-25	Low pass filter time at the	0.000 ~ 65.535 seconds		0.800						0
07-26	starting position Direct landing position control P gain	0.0~655.00 %		2.00				0		0
07-27	Low pass filter time for direct landing position control	0 ~ 1.000 seconds		0.018	3			0		0
07-28	Position control ASR P gain	0.0~1000.0		100.0						L
07-29	Position control ASR integration time I	0.000 ~ 10.000 seconds		0.100						

08 Parameters for Elevator Functions

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
08-00	Elevator's topmost floor	Floor 1 ~ 47	. 33	5	0	0	0	0		0
08-01	Elevator's down-most floor	Floor 1 ~ 47		1	0	0	0	0		0
08-02	Elevator base station	Floor 1 ~ 47		1	0	0	0	0		0
08-03	Fire base station	Floor 1 ~ 47		1	0	0	0	0		0
08-04	Elevator lock base station	Floor 1 ~ 47		1	0	0	0	0		0
08-05	Service floor 1	0 ~ FFFFh		FFFFh	0	0	0	0		0
08-06	Service floor 2	0 ~ FFFFh		FFFFh	0	0	0	0		0
08-07	Service floor 3	0 ~ FFFFh		FFFFh	0	0	0	0		0
08-08	Number of elevators for group control	1~8		1	0	0	0	0		0
08-09	Elevator No. in group control	1~8		1	0	0	0	0		0
08-10	Group control selection	b0: 1: Group control		0	0	0	0	0		0
08-11	Leveling sensor delay time	10 ~ 50ms		14	0	0	0	0		0
08-12	Security floor	Floor 1 ~ 47		1	0	0	0	0		0
08-13	Collective selection method	Collectively select all Lower collective selection Upper collective selection			0	0	0	0		0
08-14	Lower collective selection 1 start time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
08-15	Lower collective selection 1 end time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
08-16	Lower collective selection 2 start time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
08-17	Lower collective selection 2 end time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
08-18	Time Period service 1 start (hr/min)	00.00~23.59		00.00	0	0	0	0		0
08-19	Time Period service 1 end (hr/min)	00.00~23.59		00.00	0	0	0	0		0
08-20	Time Period service 1 service floor 1	Hexadecimal: 01~16 floors. Set 1 for enable answering command		FFFFh	0	0	0	0		0
08-21	Time Period service 1 service floor 2	Hexadecimal: 17~32 floors. Set 1 for enable answering command		FFFFh	0	0	0	0		0
08-22	Time Period service 1 service floor 3	Hexadecimal: 33~48 floors. Set 1 for enable answering command		FFFFh	0	0	0	0		0
08-23	Time Period service 2 start (hr/min)	-		00.00	0	0	0	0		0
08-24	Time Period service 2 end (hr/min)	00.00~23.59		00.00	0	0	0	0		0
08-25	Time Period service 2 service floor 1	Hexadecimal: 01~16 floors. Set 1 for enable answering command		FFFFh	0	0	0	0		0
08-26	Time Period service 2 service floor 2	Hexadecimal: 17~32 floors. Set 1 for enable answering command		FFFFh	0	0	0	0		0
08-27	Time Period service 2	Hexadecimal: 33~48 floors. Set 1 for enable		FFFFh	0	0	0	0		0

F	Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	08-28	Peak 1 start time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
	08-29	Peak 1 end time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
	08-30	Peak 1 floor	Floor 1 ~ 47		1	0	0	0	0		0
	08-31	Peak 2 start time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
	08-32	Peak 2 end time (hr/min)	00.00~23.59		00.00	0	0	0	0		0
	08-33	Peak 2 floor	Floor 1 ~ 47		1	0	0	0	0		0
<u>/</u>	08-34	Test floor 1	Floor 1 ~ 47		0	0	0	0	0		0
<u>/</u>	08-35	Test floor 2	Floor 1 ~ 47		0	0	0	0	0		0
<u>/</u>	08-36	Test floor 3	Floor 1 ~ 47		0	0	0	0	0		0
	08-37	Times of test	0~60000 : Times of test >60000: Infinite number of tests		0	0	0	0	0		0
	08-38	Disable external display board	0: Car-top board is valid, external display board is valid 1: Car-top board is valid, external display board is invalid 2: Car-top board is invalid, external display board is valid 3: Car-top board is invalid, external display board is invalid, external display board is invalid	.10	0	0	0	0	0		0
	08-39	Disable door open	Door open is enabled Door open is disabled Door motor jog test (under inspection mode)		0	0	0	0	0		0
	08-40	Overload function selection	Disable overload operation Enable overload operation		0	0	0	0	0		0
	08-41	Disable limit switches	D: Limit switches are enabled :Limit switches are disabled		0	0	0	0	0		0
	08-42	Anti-nuisance function	0: This function is disabled 1: This function is enabled		0	0	0	0	0		0
/	08-43	Operation speed under emergency power supply	0.00 ~ 6.67m/s		0.00	0	0	0	0		0
	08-44	Options at power shut off	0: Motor does not run 1: Motor runs under UPS power supply		0	0	0	0	0		0
	08-45	Time for returning to base station when being idle	1 ~ 240min		10	0	0	0	0		0
	08-46	Time for turning off fans and lights	0 ~ 60000 seconds		300	0	0	0	0		0
	08-47	Allowed Time interval for floor movement	0 ~ 45 seconds		45	0	0	0	0		0
	08-48	Factory function 1	b9: disabled people mode setting 1: Enabled b10:Emergency power supply PM motor self-sliding mode setting 1: Enabled b11: Emergency power supply post-stop action. Setting 1: Door open till hold time, and then door closed to position, then shut off the power 0: Door open to position and does not shut off the power b12: Door leveling after open b13: External display board continuing triggering mode		0080h	0	0	0	0		0

b0: Automatic fire operation mode enable b3: Stop output after the door motor attains to the limit b5: Operator control mode with non-stop switch setting: 1 built-in b12: Ignore returning base station after power recovery b13: For home elevator only: (no inner door) door motor handling mode b15: Output/Input display (0: terminal function status 1: terminal external status) 08-50 Hoistway self-learning 1: Start hoistway self-learning 0 No automatic reset function 0 No automatic res	Factory function 2	 b3: Stop output after the door motor attains to the limit b5: Operator control mode with non-stop switch setting: 1 built-in b12: Ignore returning base station after power recovery b13: For home elevator only: (no inner door) 	0000h	0	0	0	0	
door motor handling mode b15: Output/Input display (0: terminal function status 1: terminal external status) 08-50 Hoistway self-learning 0: Stop hoistway self-learning 1: Start hoistway self-learning 0: No automatic reset function 0 ~ 30000 times 08-52 Interval of automatic reset 0 ~ 60 seconds	08-50 Hoistway self-learning							
1: Start hoistway self-learning 0: No automatic reset function 0 ~ 30000 times 08-52 Interval of automatic reset 0 ~ 60 seconds 1: Start hoistway self-learning 0: No automatic reset function 0 ~ 30000 times 0 ~ 60 seconds 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	08-50 Hoistway self-learning	b15: Output/Input display (0: terminal function	2					
08-51 Automatic fault resets time 0 - 30000 times 0 - 30000 times 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 -			0	0	0	0	0	
08-52 Interval of automatic reset 0 ~ 60 seconds 3 o o o o o o o o o o o o o o o o o o	08-51 Automatic fault resets time	0: No automatic reset function	0	0	0	0	0	
	08-52 Interval of automatic reset		3	0	0	0	0	

09 Parameters for Door Control

★: The parameter can be set during operation

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
09-00	Number of door motors	0: 1 units 1: 2 units	100	0	0	0	0	0		0
09-01	Car-top board software version	0~99		FFFFh	0	0	0	0		0
09-02	Door motor 1 Service Floor 1	0 ~ FFFFh		FFFFh	0	0	0	0		0
09-03	Door motor 1 Service Floor 2	0 ~ FFFFh	.0	FFFFh	0	0	0	0		0
09-04	Door motor 1 Service Floor 3	0 ~ FFFFh		FFFFh	0	0	0	0		0
09-05	Door motor 2 Service Floor 1	0 ~ FFFFh		FFFFh	0	0	0	0		0
09-06	Door motor 2 Service Floor 2	0 ~ FFFFh		FFFFh	0	0	0	0	3	0
09-07	Door motor 2 Service Floor 3	0 ~ FFFFh	10	FFFFh	0	0	0	0		0
09-08	Door open time protection	5 ~ 99 seconds		10	0	0	0	0		0
09-09	Door close time protection			15	0	0	0	0		0
09-10	Door open/close times	0 ~ 20 times		0	0	0	0	0		0
09-11	Door status at movement base station	Normal door closing Open door and wait		0	0	0	0	0		0
09-12	Door open holding time by external display board	1 ~ 30 seconds		5	0	0	o	0		0
09-13	Door open holding time by in-car display board	1 ~ 30 seconds		3	0	0	0	0		0
09-14	Door open holding time at base station	1 ~ 30 seconds		10	0	0	0	0		0
09-15	Delay time for arrival alarm output	0 ~ 1000ms		0	0	0	0	0		0

10 Parameters for Car-top Board Multi-function Output/Input

★: The parameter can be set during operation

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
10-00	Car-top board input command 1	0: No function		101	0	0	0	0	0	0
10-01	Car-top board input command 2	1: Front door open limit (Normal Open)		102	0	0	0	0	0	0
10-02	Car-top board input command 3	2: Front door close limit (Normal Open)		103	0	0	0	0	0	0
10-03	Car-top board input command 4	3: Front door light curtain input (Normal Open)		105	0	0	0	0	0	0
10-04	Car-top board input command 5	4: Front door open request (Normal Open)		106	0	0	0	0	0	0
10-05	Car-top board input command 6	5: Rear door open limit (Normal Open)		107	0	0	0	0	0	0
10-06	Car-top board input command 7	6: Rear door close limit (Normal Open)		9	0	0	0	0	0	0
10-07	Car-top board input command 8	7: Rear door light curtain input (Normal Open)		10	0	0	0	0	0	0
10-08	Command board 2 input command 1	8: Rear door open request (Normal Open)		0	0	0	0	0	0	0
10-09	Command board 2 input command 2	9: Overload input (Normal Open)		0	0	0	0	0	0	0
10-10	Command board 2 input command 3	10: Full load input (Normal Open)		0	0	0	0	0	0	0
10-11	Command board 2 input command 4	11: Front door open button (Normal Open)	3	0	0	0	0	0	0	0
10-12	Command board 2 input command 5	12: Front door close button (Normal Open)		0	0	0	0	0	0	0
10-13	Command board 2 input command 6	13: Front door open delay button (Normal Open)		0	0	0	0	0	0	0
10-14	Command board 2 input command 7	14: VIP mode switch (Normal Open)		0	0	0	0	0	0	0
10-15	Command board 2 input command 8	15: Operator control switch (Normal Open)		0	0	0	0	0	0	0
10-16	Command board 1 input command 1	16: Operator non-stop control switch (Normal Open)		11	0	0	0	0	0	0
10-17	Command board 1 input command 2	17: Independent operation switch (Normal Open)		12	0	0	0	0	0	0
10-18	Command board 1 input command 3	18: 1 st level fire rescue switch (Normal Open)		13	0	0	0	0	0	0
10-19	Command board 1 input command 4	19: Car-top inspection switch (Normal Open)		14	0	0	0	0	0	0
10-20	Command board 1 input command 5	20: Car-top inspection up-going (Normal Open)		15	0	0	0	0	0	0
10-21	Command board 1 input command 6	21: Car-top inspection down-going (Normal Open)		16	0	0	0	0	0	0
10-22	Command board 1 input command 7	22: Emergency stop input (Normal Open)		17	0	0	0	0	0	0
10-23	Command board 1 input command 8	23: Light control input (Normal Open)		18	0	0	0	0	0	0
ne de		24: Fan control input (Normal Open)25: Rear door open button (Normal Open)26: Rear door close button (Normal Open)27: Rear door open delay button (Normal Open)		N. co						

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
		28: Operator direction up-going switch (Normal								
		Open)								
		29: Operator direction down-going switch								
		(Normal Open)								
		30: Jog up-going (Normal Open)								
		31: Jog down-going (Normal Open)								
		32: Light load switch input (Normal Open)				•				
		33: Front door safety panel (Normal Open)								
		34: Rear door safety panel (Normal Open)								
	0	101: Front door open limit (Normal Close)								
	P. 1	102: Front door close limit (Normal Close)								
		103: Front door light curtain input (Normal		100						
		Close)								
	G	104: Front door open request (Normal Close)					3			
		105: Rear door open limit (Normal Close)								
		106: Rear door close limit (Normal Close)					0.			
		` '								
		107: Rear door light curtain input (Normal								
		Close)								
		108: Rear door open request (Normal Close)								
		109: Overload input (Normal Close)								
		110: Full load input (Normal Close)								
		111: Front door open button (Normal Close)								
		112: Front door close button (Normal Close)								
		113: Front door open delay button (Normal								
		Close)								
		114: VIP mode switch (Normal Close)								
		115: Operator control switch (Normal Close)								
		116: Operator non-stop control switch (Normal								
		Close)								
		117: Independent operation switch (Normal								
	A 6"	Close)								
		118: 1 st level fire rescue switch (Normal Close)								
		119: Car-top inspection switch (Normal Close)								
	4 0	120: Car-top inspection up-going (Normal								
		Close)								
		121: Car-top inspection down-going (Normal								
		Close)								
		122: Emergency stop input (Normal Close)								
		123: Light control input (Normal Close)								
		124: Fan control input (Normal Close)								
		125: Rear door open button (Normal Close)								
	7	126: Rear door close button (Normal Close)								
		127: Rear door open delay button (Normal								
		Close)								
	4	128: Operator direction up-going switch (Normal								
		Close)								
		129: Operator direction down-going switch								
	0, 3									
		(Normal Close)								
		130: Jog up-going (Normal Close)								
		131: Jog down-going (Normal Close)			-		_			\vdash
	at 9	132: Light load switch input (Normal Close)			-		8.7	•		\vdash
		133: Front door safety panel (Normal Close)				3.3	100			_
		134: Rear door safety panel (Normal Close)			A.					
10-24	Car-top board output	0: No function		1	0	0	0	0	0	0
	command 1	5. 10 Idilodoli								L
10-25	Car-top board output	1: Front door open output (Normal Open)		2	0	0	0	0	0	0
	command 2	1: Front door open output (Normal Open)								

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	1000
10-26	Car-top board output command 3	2: Front door close output (Normal Open)		3	0	0	0	0	0	
10-27	Car-top board output command 4	3: Rear door open output (Normal Open)		4	0	0	0	0	0	T
10-28	Car-top board output command 5	4: Rear door close output (Normal Open)		5	0	0	0	0	0	(
10-29	Car-top board output command 6	5: Overload signal output (communication)(Normal Open)		6	0	0	0	0	0	
10-30	Car-top board output command 7	6: Full-load signal output (Normal Open)		7	0	0	0	0	0	
10-31	Car-top board output command 8	7: Buzzer output (Normal Open)		8	0	0	0	0	0	C
10-32	Command board 2 output command 1	8: Light output (Normal Open)		0	0	0	0	0	0	C
10-33	command 2	9: Fan output (Normal Open)		0	0	0	0	0	0	C
10-34	command 3	10: Front door is opening (Normal Open)		0	0	0	0	0	0	C
10-35	Command board 2 output command 4	11: Front door is closing (Normal Open)		0	0	0	0	0	0	C
10-36	command 5	12: Front door open delay display (Normal Open)		0	0	0	0	0	0	C
10-37	command 6	13: Non-stop operation display (Normal Open)		0	0	0	0	0	0	С
10-38	command 7	14: Operation control display (Normal Open)		0	0	0	0	0	0	
10-39	command 8	15: Operation direction change display (Normal Open)		0	0	0	0	0	0	C
10-40	command 1	16: Independent operation display (Normal Open)	3	10	0	0	0	0	0	C
10-41	Command board 1 output command 2	17: 1 st level fire rescue display (Normal Open)		11	0	0	0	0	0	C
10-42	command 3	18: Elevator landing (Normal Open)		12	0	0	0	0	0	0
10-43	command 4	19: Elevator stops (Normal Open)		13	0	0	0	0	0	C
10-44	command 5	20: Elevator up-going output (Normal Open)		14	0	0	0	0	0	C
10-45	command 6	21: Elevator down-going output (Normal Open)		15	0	0	0	0	0	С
10-46	command 7	22: Error display output (Normal Open)		16	0	0	0	0	0	
10-47	command 8	23: Front door reset output (Normal Open)		17	0	0	0	0	0	C
10-48	Car-top board output command 9	24: Front door slow close output (Normal Open)		0	0	0	0	0	0	C
	ice in	25: Rear door reset output (Normal Open) 26: Rear door slow close output (Normal Open)								
		27: Rear door is opening (Normal Open) 28: Rear door is closing (Normal Open)								
		29: Rear door open delay display (Normal Open)								•
		101: Front door open output (Normal Close)102: Front door close output (Normal Close)								
	777	103: Rear door open output (Normal Close)								
		104: Rear door close output (Normal Close)								

Parameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
		105: Overload signal output								
		(communication)(Normal Close)								
	10'	106: Full-load signal output (Normal Close)								
		107: Buzzer output (Normal Close)								
		108: Light output (Normal Close)								-
		109: Fan output (Normal Close)								
		110: Front door is opening (Normal Close)								
		111: Front door is closing (Normal Close)								
	d a	112: Front door open delay display (Normal Close)								
	P. 12	113: Non-stop operation display (Normal Close)								
		114: Operation control display (Normal Close)								
	W.C.	115: Operation direction change display (Normal Close)								
		116: Independent operation display (Normal Close)			1					
	1.00	117: 1 st level fire rescue display (Normal Close)								
		118: Elevator landing (Normal Close)								
		119: Elevator stops (Normal Close)		(6)						
	.0	120: Elevator up-going output (Normal Close)								
	Will.	121: Elevator down-going output (Normal Close)								
		122: Error display output (Normal Close)								
		123: Front door reset output (Normal Close)								
		124: Front door slow close output (Normal								
		Close)								
		125: Rear door reset output (Normal Close)								
	37	126: Rear door slow close output (Normal Close)								
		127: Rear door is opening (Normal Close)								
	A 6"	128: Rear door is closing (Normal Close)								
		129: Rear door open delay display (Normal		6						
		Close)								
10-49	Digital input Operation direction 1	0 ~ FFFFh		0	0	0	0	0	0	0
10-50	Digital input Operation	V			+		-		-	\vdash
10 00	direction 2	0 ~ FFFFh		0	0	0	0	0	0	0
10-51	Digital output direction 1			0	0	0	0	0	0	0
10-52	Digital output direction 2			0	0	0	0	0	0	0

11 Parameters for Protection

☑ represents that the parameter can be configured as shown/hidden

							_				
P	arameter code	Function of the parameter	Parameter range	level	Default value	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	11-00	Detection Time of Mechanical Brake	0.00 ~ 10.00 seconds		0.00	0	0	0	0	0	0
/	11-01	Detection Time of contactor	0.00 ~ 10.00 seconds		0.00	0	0	0	0	0	0
/	11-02	Brake Chopper Level	230Vseries: 350.0 ~ 450.0Vdc 460Vseries: 700.0 ~ 900.0Vdc		380.0 760.0	0	0	0	0	0	0
	11-03	Low voltage level	230Vseries: 160.0 ~ 220.0Vdc 460Vseries: 320.0 ~ 440.0Vdc	V	180.0 360.0	0	0	0	0	0	0
	11-04	Phase-loss protection	Warn and keep operation Warn and ramp to stop Warn and coast to stop	Ø	2	0	0	0	0	0	0
/ [11-05	Current limit	0~200%	Ø	150				0	0	0
	11-06	Heat Sink Over-heat (OH) Warning	0.0~110.0℃	Ø	90.0	0	0	0	0	0	0
	11-07	PTC (Positive Temperature Coefficient) Detection Treatment	Warn and keep operation Warn and ramp to stop	Ø	0	0	0	0	0	0	0
1	11-08	PTC level	0.0~100.0%	\square	50.0	0	0	0	0	0	0
	11-09	Filter Time for PTC Detection	0.00 ~ 10.00 seconds		0.20	0	0	0	0	0	0
	11-10	Power supply voltage under emergency operation	230Vseries: 48.0 ~ 375.0Vdc 460Vseries: 96.0 ~ 750.0Vdc		48.0 96.0	0	0	0	0	0	0
	11-11	Power supply capacity under emergency operation	0.0 ~ 100.0KVA	Ø	0.0	0	0	0	0	0	0
	11-12	Phase loss detection of motor output	Disable phase loss protection Enable phase loss protection	V	0	0	0	0	0	0	0
	11-13	Error action treatment	bit0 = 0: Low-voltage error and coast to stop bit0 = 1: Low-voltage warning and coast to stop bit1 = 0: Fan error and coast to stop bit1 = 1: Fan warning and coast to stop	Ø	2	0	0	0	0	0	0
	11-14	Check Torque Output Function	0: Disable 1: Enable	Ø	0	0	0	0	0	0	0
	11-15	Encoder feedback signal error treatment	Warn and keep operation Warn and ramp to stop Warn and stop operation	Ø	2		0	6	0	0	
	11-16	Detection time for encoder feedback fault	0.0 ~ 10.0 seconds	V	1.0		0		0	0	0
_	11-17	Encoder stall level	0 ~ 120%/s (0: no effect)	Ø	115		0	0	0		0
	11-18	Encoder stall detection time	0.0 ~ 2.0 seconds		0.1		0	0	0		0
	11-19	Encoder slip range	0 ~ 50%/s (0: no effect)	Ø	50		0	0	0	(0	0
	11-20	Encoder slip detection time	0.0 ~ 10.0 seconds		0.5		0	0	0		0
	11-21	Encoder stall and slip treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	V	2		0	0	0		


12 Parameters for Communication


☑ represents that the parameter can be configured as shown/hidden

Parameter code	Function of the parameter	Parameter range	level	Default value	٧F	VFPG	SVC)))	- C))) :
12-00	Communication address	1~254		1	0	0	0	0	0	0
12-01	Communication transmission rate (Keypad)	4.8 ~ 115.2Kbps		19.2	0	0	0	0	0	0
12-02	Transmission fault treatment (Keypad)	O: Warn and continue operation I: Warn and ramp to stop 2: Reserved 3: Bypass without treatment		13	0	0	0	0	0	0
12-03	Communication transmission rate (Remote)	4.8 ~ 115.2Kbps		19.2	0	0	0	0	0	0
12-04	Communication format (Remote)	0: 7N1 (ASCII) 1: 7N2 (ASCII) 2: 7E1 (ASCII) 3: 7O1 (ASCII) 4: 7E2 (ASCII) 5: 7O2 (ASCII) 6: 8N1 (ASCII) 7: 8N2 (ASCII) 8: 8E1 (ASCII)	11/10	13			5	•		
	Hill on many	9: 801 (ASCII) 10: 8E2 (ASCII) 11: 802 (ASCII) 12: 8N1 (RTU) 13: 8N2 (RTU) 14: 8E1 (RTU) 15: 801 (RTU) 16: 8E2 (RTU) 17: 802 (RTU)	5. 14,		0	0	0	0	0	0
12-05	Transmission fault treatment (Keypad)	O: Warn and continue operation 1: Warn and ramp to stop 2: Reserved 3: Bypass without treatment	Ø	3	0	0	0	0	0	0
12-06	Time-out detection (Keypad)	0.0 ~ 100.0 seconds	Ø	0.0	0	0	0	0	0	0
12-07	Transmission fault treatment (Remote)	O: Warn and continue operation I: Warn and ramp to stop 2: Reserved 3: Bypass without treatment	Ø	3	0	0	0	0	0	0
12-08	Time-out detection (Remote)	0.0 ~ 100.0 seconds	Ø	0.0	0	0	0	0	0	0
12-09	Communication response delay time	0.0 ~ 200ms	Ø	2.0	0	0	0	0	0	0


5 Product Dimensions


Frame No. B IED022A21A, IED037A21A, IED040A23A, IED040A43A







Frame No. C










Unit: mm [inch]

Fram e No.	W	W1	H	H1	H2	Н3	D	Ø	Ø1	Ø2	Ø3
С	235	204	350	337	320	_ <	136	6.5	-	34	22
	[9.25]	[8.03]	[13.78]	[13.27]	[12.60]		[5.35]	[0.26]	_	[1.34]	[0.87]



Frame No. C: IED055A23A/43A, IED075A23A/43A, IED110A23A/43A,

Frame No. D




Unit: mm [inch]


Fram e No.	W	W1	Н	H1	H2	Н3	D	Ø	Ø1	Ø2	Ø3
	255.0	226.0	403.8	384.0	360.0	21.9	168.0	8.5	44	34	22
D	[10.04]	[8.90]	[15.90]	[15.12]	[14.17]	[0.86]	[6.61]	[0.33]	[1.73]	[1.34]	[0.87]




Frame No. D: IED150A23A/43A, IED185A23A/43A, IED220A23A/43A,

Frame No. E







Unit: mm [inch]

Fram e No.	W	W1	Н	H1	H2	D	D1:	D2:	S1	S2	S 3
E4	370.0	335.0	550.0	589.0	560.0	260.0	132.5	18.0	13.0	13.0	18.0
E1	[14.57]	[13.19]	[21.65]	[23.19]	[22.05]	[10.24]	[5.22]	[0.71]	[0.51]	[0.51]	[0.71]



Frame No. E1: IED300A43A, IED370A43A, IED450A43A,

6 Error Codes

KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
oc R	Fault ocA Oc at accel	Over current during acceleration	Check if the bolts on the AC motor driver and the motor are loose. Check the connection from U-V-W to the motor for any improper insulation.
WHID.		Allahin.	Increase the acceleration time. Replace with an AC motor driver with a larger output capacity.
ocd	Fault ocd Oc at decel	Over current during deceleration	Check the connection from U-V-W to the motor for any improper insulation. Increase the deceleration time. Replace with an AC motor driver with a larger output capacity.
ocn	Fault ocn Oc at normal SPD	Over current during movement	Check the connection from U-V-W to the motor for any improper insulation. Check if the motor is jammed. Replace with an AC motor driver with a larger output capacity.
ម្ចី ប្រ	Fault GFF Ground fault	is larger than 50% of the AC motor driver's rated	Check the connection to the motor for short circuit or ground. Make sure if the IGBT power module is damaged.
	HAND	protection is used for protecting the AC motor driver detects AC motor driver detects	Wigu Manarita
occ	Fault occ Short Circuit	short circuit between the IGBT module's upper and lower bridges.	Return to factory for repair.

KPED-CE01			0, 0
Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
oc S	Fault ocS Oc at stop	Over current when the elevator stops Malfunction of the voltage detection circuit.	Return to factory for repair.
ουR	Fault ovA Ov at accel	motor driver detects over	Check if the input voltage is within the AC motor driver's rated voltage range; and monitor if there is any voltage surge. If the voltage surge due to the motor's inertia causes over-voltage at the AC motor driver's internal DC high-voltage side, please increase the deceleration time or install a brake resistor (optional).
Wild	Fault ovd		Check if the input voltage is within the AC motor driver's rated voltage range; and monitor if there is any voltage surge. If the voltage surge due to
000	Ov at decei		the motor's inertia causes over-voltage at the AC motor driver's internal DC high-voltage side, please increase the deceleration time or install a
39.11	Fault ovn Ov at normal SPD	movement, the AC motor	brake resistor (optional). Check if the input voltage is within the AC motor driver's rated voltage range; and monitor if there to any voltage surge. If the voltage surge due to
000	. IP. IIII. CIT		the motor's inertia causes over-voltage at the AC motor driver's internal DC high-voltage side, please increase the deceleration time or install a brake resistor (optional).
005	Fault ovS Ov at stop	Over-voltage when the elevator stops. Malfunction of the voltage detection circuit	Check if the input voltage is within the AC motor driver's rated voltage range; and monitor if there
LuA	Fault LvA Lv at accel	During acceleration, the AC motor driver detects that the voltage at the internal DC high-voltage side is lower than the setting of Parameter 11-03.	Check if the voltage of the input power supply is normal. Check if there is any sudden heavy load.

KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
۲۰۵	Fault Lvd Lv at decel	During deceleration, the AC motor driver detects that the voltage at the internal DC high-voltage side is lower than the setting of Parameter 11-03.	Check if the voltage of the input power supply is normal. Check if there is any sudden heavy load.
Lun	Fault Lvn Lv at normal SPD	During constant-speed movement, the AC motor driver detects that the voltage at the internal DC high-voltage side is lower than the setting of Parameter 11-03.	Check if the voltage of the input power supply is normal. Check if there is any sudden heavy load.
٤٠5	Fault LvS Lv at stop	When the elevator stops the AC motor driver detects that the voltage at the internal DC high-voltage side is lower than the setting of Parameter 11-03.	Check if the voltage of the input power supply is normal. Check if there is any sudden heavy load.
የዘር	Fault PHL Phase loss	Phase loss protection	Check if the single-phase input is used for the three-phase model or there is any phase loss.
oX:	Fault OH1		Check if the ambient temperature is too high. Check if the heat dissipation plate for any external objects. Check if the fan is running. Check if the AC motor driver has sufficient space.
0 H C	Fault oH2	overheat of the IGBT with	Check if the ambient temperature is too high. Check if the heat dissipation plate for any external objects. Check if the fan is running. Check if the AC motor driver has sufficient space.
EH Io	Fault tH1o Thermo 1 open	IGBT temperature sensing circuit has malfunction	Return to factory for repair.

1/055 050/			
KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
£#20	Fault tH2o Thermo 2 open	Capacitor module temperature sensing circuit has malfunction	
FRn	Fault Fan Fan signal error	Fan has a malfunction.	Check if the fan is blocked. Return to factory for repair.
οĹ	Fault oL Overload		Check if the motor is overloaded. Increase the output capacity of the AC motor driver.
EoL I	Fault EoL1 Thermal relay 1		Check if Motor 1 is overloaded. Check if the (02-01) motor's rated current setting is proper.
o#3	Fault oH3 Motor Overheat	AC motor driver detects internal overheat which is higher than the protection level (11-08 PTC level)	Check if the motor is jammed. Check if the ambient temperature is too high.
061	Fault ot1 Over torque 1	Electronic thermally actuated relay 1 protection is activated	Check if the (02-01) motor's rated current setting
062	Fault ot2 Over torque 2	Electronic thermally actuated relay 2 protection is activated.	Check if the motor is overloaded. Check if the (02-01) motor's rated current setting is proper. Increase the motor's capacity.
cF:	Fault cF1 EEPROM write err	Memory write error.	Press the RESET button to reset the parameters to factory defaults. If this method is not working, return to factory for repair.
c F 2	Fault cF2 EEPROM read err	Memory read error.	Press the RESET button to reset the parameters to factory defaults. If this method neither is nor working, return to factory for repair.

KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
c d O	Fault cd0 las sensor err	Current detection circui error.	t After re-connecting the power supply, if the error still exists, return to factory for repair.
cd:	Fault cd1 las sensor err	U-phase current detection error.	After re-connecting the power supply, if the error still exists, return to factory for repair.
cd?	Fault cd2 Ibs sensor err	V-phase current detection error.	After re- connecting the power supply, if the error still exists, return to factory for repair.
c d 3	Fault cd3	W-phase current detection error.	After re- connecting the power supply, if the error still exists, return to factory for repair.
88K	Fault Hd0 cc HW error	cc protection hardware circuit error .	eAfter re- connecting the power supply, if the error still exists, return to factory for repair.
1 6 K	Fault Hd1 Oc HW error	oc protection hardware circuit error.	eAfter re-connecting the power supply, if the error still exists, return to factory for repair.
X45	Fault Hd2 Ov HW error	ov protection hardware circuit error.	eAfter re- connecting the power supply, if the error still exists, return to factory for repair.
X43	Fault Hd3 occ HW error	occ protection hardware circuit error.	After re- connecting the power supply, if the error still exists, return to factory for repair.
808	Fault AUE Auto tuning err	Motor paramete auto-tuning error.	Check if the motor's connection is correct. rCheck if the motor's capacity and the parameter settings are correct. Re-test

A.

KPED-CE01 Displayed Code	Description of Failure	Solutions
Fault PGF1 PG Fbk error	PG feedback error	If PG feedback control is enabled, check if the Encoder's parameter setting is correct (02-07≠0).
Fault PGF2 PG Fbk loss	PG feedback is disconnected.	Check the PG feedback connection.
Fault PGF3 PG Fbk over SPD	PG feedback over speed	Check the PG feedback connection. Check if the PI gain and the acceleration/deceleration settings are proper. Adjust the stall detection parameters (Parameters 11-17 ~ 11-18). Return to factory for repair.
Fault PGF4 PG Fbk deviate	PG feedback deviation error.	Check the PG feedback connection. Check if the PI gain and the acceleration/deceleration settings are proper. Adjust the stall detection parameters (Parameters 11-17 ~ 11-18). Return to factory for repair.
Fault EF External fault	When the external EF terminals close, the AC motor driver stops output.	After clearing the cause of the error, press the
Fault EF1 Emergency stop	When the external multi-function input terminals are setting emergency stop, the AC motor driver stops output.	After clearing the cause of the error, press the "RESET" button.
Fault Pcod Password error	Password error for three times.	Refer to the settings of parameters 01-6 ~ 01-07. Please turn off the power, re-start, and then enter the correct password.
Fault CE01 PC err command	Invalid communication command.	Check if the communication command is correct (the communication command must be 03, 06, 10, and 63).
	PGF1 PGF1 PGFbk error HAND Fault PGF2 PG Fbk loss HAND Fault PGF3 PG Fbk over SPD Fault PGF4 PG Fbk deviate HAND Fault EF External fault EF External fault EF1 Emergency stop HAND Fault CE01 HAND Fault CE01	Displayed Code Pault PGF1 PG Fbk error

KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
5883	Fault CE02 PC err address	Invalid communication data address (00H ~ 254H).	Check if communication data length is correct.
C E O 3	Fault CE03 PC err data	Invalid communication data values.	Check if the communication data values exceed the maximum/minimum values.
C E O Y	Fault CE04 PC slave fault	Write data to the read-only address.	Check if the communication address is correct.
CE 10	Fault CE10 PC time out	Communication time-out.	Check if the communication connection is normal.
CP 10	Fault CP10 PU time out		Check if the communication connection is normal. Check if the digital control unit is working normally.
ьF	Fault bF Braking fault	Driver detects errors from the braking transistor.	After press the RESET button, if the message bF still exists, please return to factory for repair.
5-5	Fault SrY Safety loop error	IED safety loop detection error.	Check if the safety loop detection is selected correctly (SW3). Check if the IED safety loop is installed correctly (J8). Check if the output operation is normal.
NbF	Fault MbF Mech. Brake error	Mechanical brake feedback signal does not match the release signal.	Make sure if the mechanical brake signal is correct. Make sure if the mechanical brake operation detection time (11-00) is configured correctly.
PGFS	Fault PGF5 PG Fbk error	PG hardware detection error.	Check the PG feedback connection. After the PG feedback is corrected, if this error message still exists, please return to factory for repair.

KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
ner	Fault MCF contactor Fail	Solenoid valve actuation signal does not match the release signal.	Make sure if the solenoid valve actuation signal is correct. Make sure if the solenoid valve operation detection time (11-01) is configured correctly.
NPKL	Fault MPHL Motor Phase Loss	Output phase loss.	Make sure if the connection from the IED to the motor is normal. Return to factory for repair.
co	Fault CO CAN overwrite	CAN communication packet error.	Check if the connection for CAN communication is correct without any noise.
cto	Fault cto CAN timeout	CAN communication time-out.	Check if the connection for CAN communication is correct without any noise.
Ldr	Fault Ldr Door Zone Err	The stop position does not match the value from the	Check if the leveling signal is normal. Check if the leveling time-out parameter is
Lto	Fault Lto Leveling Timeout	received for a time longer	Check if the leveling signal is normal. Check if the leveling time-out parameter is configured correctly. Check the elevator for possible slip.
Lu	Fault Lu Level Up Error	Upper leveling signal is not received at stop.	Check if the upper leveling signal is normal. Check if the leveling plate has sufficient length. Check the parking deceleration parameter setting; decrease the deceleration; increase the parking time.
Ld	Fault Ld Level Down Error	Down leveling signal is not received at stop.	Check if the lower leveling signal is normal. Check if the leveling plate has sufficient length. Check the parking deceleration parameter setting; decrease the deceleration; increase the parking time.

KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
do	Fault do Door Opened		Check if the door close limit signal is normal. Check if the communication between the IED and the car-top board is normal.
dof	Fault doF Door Open Fail	The automatic re-tries for door open exceed the parameter setting.	
<i>4</i> [F	Fault dCF Door Close Fail	The automatic re-tries for door close exceed the parameter setting.	
dot	Fault dot Open Timeout	received for a time longer	Check if the door close limit signal is normal. Check if the door motor is working normally. Check if the communication between the IED and the car-top board is normal.
6 [E	Fault dCt Close Timeout	When the door is closing the door close to position signal is not received for a time longer than the setting of the parameter 09-09.	Check if the door close limit signal is normal. Check if the door motor is working normally.
೬೮४	Fault tUd Welltune Undone	Hoistway self-learning error.	Re-execute the hoistway self-learning process. Make sure if the hoistway signal is normal.
rld	Fault rLd Up Limit Switch	Upper limit signal is triggered during movement.	Check the elevator for possible slip. Check the corresponding terminals on the IED. Check if the limit switch signal is normal.
-60	Fault rLu Dn Limit Switch	Move down to the lower limit.	Check the elevator for possible slip. Check the corresponding terminals on the IED. Check if the limit switch signal is normal.

KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
551	Fault SSL System Safe Lock	ILD Haldware ellor.	Check if the IED can still work. Return to factory for repair.
SAF	Fault SAF Safe Loop Lost	Safety loop signal error.	Check if all the switches in the external safety loop are normal.
Srun	Fault Srun Motor Fb Lost	Output contact feedback signal error	Make sure if the input terminal from the output feedback signal to the IED is normal without any sticking. Make sure if the corresponding relay output is normal.
Sbr	Fault Sbr Brake Fb Lost	Contracting brake contact feedback signal error.	Make sure if the input terminal from the contracting brake feedback signal to the IED is normal without any sticking. Make sure if the contracting brake relay output is normal.
5888	Fault SdbP Door Bypass Lost	Door open bypass contact feedback signal error.	Make sure if the input terminal from the door open bypass feedback signal to the IED is normal without any sticking. Make sure if the door open bypass relay has normal output.
Sdr	Fault Sdr Door Fb Lost	orror	Make sure if all the switches in the door lock circuit are normal.
trlU	Fault trLU Tune Limit Up	valid, both the two leveling	Make sure if the input function is configured correctly: upper limit switch. Adjust the position of the upper limit switch.
trid	Fault trLd Tune Limit Down	configured.	Make sure if the input function is configured correctly: lower limit switch. Adjust the position of the lower limit switch.

KPED-CE01 Displayed	KPED-CE01	Description of Failure	Solutions
Code	Displayed Code	Description of Failure	Solutions
	ar.	are valid. The lower limit	7/1/4 4/0
		switch is installed at too	
		high a position.	11/2 10/2
	HAND	Coercionary deceleration	MIN MIN
	Fault	position is determined from	
	tdd1	self-learning, but the signal	
	Tune Dec Dn1	is not received. The signal is	Make sure the switch is installed correctly, and the
		triggered several times. The	signal is stably transmitted.
6001		signal is not stable.	Make sure the signal wire is connected to the
		The sequence of the	correct input terminal; check the parameter setting
		hoistway signals are not	of the multi-function input.
		correct; this input function is	.00
		configured but there is no	Min. Wic. M.
		such switch in the hoistway.	Ch.
	HAND	Coercionary deceleration	
	Fault	position is determined from	14, 116,
	tdd2	self-learning, but the signal	110, 10,
(0)	Tune Dec Dn2	is not received. The signal is	Make sure the switch is installed correctly, and the
		triggered several times. The	signal is stably transmitted.
6006		signal is not stable.	Make sure the signal wire is connected to the
		The sequence of the	correct input terminal; check the parameter setting
		hoistway signals are not	of the multi-function input.
		correct; this input function is	
		configured but there is no	76 " 20 " 180"
110.		such switch in the hoistway.	y. Iller
	HAND	Coercionary deceleration	.0
	Fault	position is determined from	Min. Str.c.
	tdd3	self-learning, but the signal	'May
	Tune Dec Dn3	is not received. The signal is	Make sure the switch is installed correctly, and the
		triggered several times. The	signal is stably transmitted.
6003		signal is not stable.	Make sure the signal wire is connected to the
		The sequence of the	correct input terminal; check the parameter setting
	20	hoistway signals are not	of the multi-function input.
		correct; this input function is	116.
		configured but there is no	
		such switch in the hoistway.	W. M.

	<u> </u>		
KPED-CE01 Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Solutions
M.ch.	Fault tUd1 Tune Dec Up1	Coercionary deceleration position is determined from self-learning, but the signal is not received. The signal is triggered several times. The	Make sure the switch is installed correctly, and the
৮ሀ ሪ፣		signal is not stable.	Make sure the signal wire is connected to the correct input terminal; check the parameter setting of the multi-function input.
2. Andy	Fault tUd2 Tune Dec Up2	Coercionary deceleration position is determined from self-learning, but the signal is not received. The signal is	Make sure the switch is installed correctly, and the
£845		The sequence of the hoistway signals are not correct; this input function is configured but there is no	Make sure the signal wire is connected to the correct input terminal; check the parameter setting of the multi-function input.
と ひよ3	Fault tUd3 Tune Dec Up3	triggered several times. The	Make sure the switch is installed correctly, and the
	L Many.		correct input terminal; check the parameter setting of the multi-function input.
866	Fault tLC Tune Level Cnt	match the parameter	Make sure the parameter settings, and make sure that the leveling switches/plates are installed correctly.

Displayed Code	KPED-CE01 Displayed Code	Description of Failure	Mill	Solutions	Ann.
£U35	Fault tUdS Tune Up Dn Seq	Triggering sequence of the leveling switches is no correct.	ot Make sure tha	t the upper/lowe	
と Uる8	Fault tUdA Tune Up Dn All	Two leveling switches are triggered at the same time.	eare installed to t	the upper/lower le he correct input te two signal w	erminals. Make
	IIII.co	14/1/2		<u></u>	